



*See the possibilities*

## *User's Manual*

# ***BM-141GE, OP22-5-1*** ***BB-141GE, OP22-5-1***

*1.4-megapixel Monochrome / Color  
Progressive Scan GigE Vision Camera  
With Extended Temperature Operation*

Document Version: Rev A  
Document P/N : 10745  
October 2010





## Notice

The material contained in this manual consists of information that is proprietary to JAI Inc., and may only be used by the purchasers of the product. JAI Inc. makes no warranty for the use of its product and assumes no responsibility for any errors which may appear or for damages resulting from the use of the information contained herein. JAI Inc. reserves the right to make changes without notice.

Company and product names mentioned in this manual are trademarks or registered trademarks of their respective owners.

## Warranty

For information about the warranty, please contact your factory representative.

## Certifications

### CE compliance

As defined by the Directive 2004/108/EC of the European Parliament and of the Council, EMC (Electromagnetic compatibility), JAI Inc. declares that BM-141GE and BB-141GE comply with the following provisions applying to its standards.

EN 61000-6-3 (Generic emission standard part 1)

EN 61000-6-2 (Generic immunity standard part 1)

### FCC

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into a outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


### Warning

Changes or modifications to this unit not expressly approved by the party responsible for FCC compliance could void the user's authority to operate the equipment.

BM-141GE

## Supplement

The following statement is related to the regulation on “ Measures for the Administration of the control of Pollution by Electronic Information Products “ , known as “ China RoHS “. The table shows contained Hazardous Substances in this camera.

 mark shows that the environment-friendly use period of contained Hazardous Substances is 15 years.

### 重要注意事项

#### 有毒，有害物质或元素名称及含量表

根据中华人民共和国信息产业部『电子信息产品污染控制管理办法』，本产品《有毒，有害物质或元素名称及含量表》如下。

部件名称	有毒有害物质或元素					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PPB)	多溴二苯醚 (PBDE)
螺丝固定座	×	○	○	○	○	○
.....	.....	.....	.....	.....	.....	.....

○：表示该有毒有害物质在该部件所有均质材料中的含量均在SJ/T11363-2006规定的限量要求以下。  
 ×：表示该有毒有害物质至少在该部件的某一均质材料中的含量超出SJ/T11363-2006规定的限量要求。  
 (企业可在此处、根据实际情况对上表中打“×”的技术原因进行进一步说明。)



#### 环保使用期限


电子信息产品中含有的有毒有害物质或元素在正常使用的条件下不会发生外泄或突变、电子信息产品用户使用该电子信息产品不会对环境造成严重污染或对基人身、财产造成严重损害的期限。

数字「15」为期限15年。

BB-141GE

## Supplement

The following statement is related to the regulation on “ Measures for the Administration of the control of Pollution by Electronic Information Products “ , known as “ China RoHS “ . The table shows contained Hazardous Substances in this camera.

 mark shows that the environment-friendly use period of contained Hazardous Substances is 15 years.

### 重要注意事项

#### 有毒，有害物质或元素名称及含量表

根据中华人民共和国信息产业部『电子信息产品污染控制管理办法』，本产品《有毒，有害物质或元素名称及含量表》如下。

部件名称	有毒有害物质或元素					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PPB)	多溴二苯醚 (PBDE)
螺丝固定座	×	○	○	○	○	○
光学滤色镜	×	○	×	○	○	○
.....	.....	.....	.....	.....	.....	.....

○：表示该有毒有害物质在该部件所有均质材料中的含量均在SJ/T11363-2006规定的限量要求以下。  
 ×：表示该有毒有害物质至少在该部件的某一均质材料中的含量超出SJ/T11363-2006规定的限量要求。  
 （企业可在此处，根据实际情况对上表中打“×”的技术原因进行进一步说明。）



#### 环保使用期限

电子信息产品中含有的有毒有害物质或元素在正常使用的条件下不会发生外泄或突变、电子信息产品用户使用该电子信息产品不会对环境造成严重污染或对基人身、财产造成严重损害的期限。

数字「15」为期限15年。

Table of Contents

- 1. General ..... 6
- 2. Camera nomenclature ..... 6
- 3. Main Features ..... 7
- 4. Locations and Functions..... 8
  - 4.1. Locations and functions..... 8
  - 4.2. Flange back adjustment ..... 9
- 5. Pin Assignment ..... 10
  - 5.1 12-pin Multi-connector (DC-in/GPIO/Iris Video).....10
  - 5.2 Digital Output Connector for Gigabit Ethernet .....10
  - 5.3 D-sub 9 pin connector for GPIO (Auxiliary).....10
  - 5.4 Internal DIP switch .....11
- 6. GPIO (Inputs and outputs) ..... 12
  - 6.1. Overview .....12
    - 6.1.1 LUT (Cross Point Switch) .....13
    - 6.1.2 12-bit Counter .....13
    - 6.1.3 Pulse Generators (0 to 1).....13
  - 6.2 Opto-isolated Inputs/Outputs.....13
    - 6.2.1 Recommended External Input circuit diagram for customer .....14
    - 6.2.2 Recommended External Output circuit diagram for customer .....14
    - 6.2.3 Optical Interface Specifications .....14
  - 6.3. Inputs and outputs table.....15
  - 6.4. Configuring the GPIO module (register settings) .....16
    - 6.4.1 Input /Output Signal Selector .....16
    - 6.4.2 12-bit counter .....17
    - 6.4.3 Pulse generators (19 bit x 2) .....18
  - 6.5. GPIO programming examples .....20
    - 6.5.1 GPIO Plus PWC shutter .....20
    - 6.5.2 Internal Trigger Generator.....21
- 7. GigE Vision Streaming Protocol (GVSP) ..... 22
  - 7.1. Digital Video Output (Bit Allocation) .....22
  - 7.2. Bit Allocation (Pixel Format / Pixel Type) - BM-141GE (monochrome) .....22
    - 7.2.1 GVSP\_PIX\_MONO8 (8bit).....22
    - 7.2.2 GVSP\_PIX\_MONO10 (10bit) .....22
    - 7.2.3 GVSP\_PIX\_MONO10\_PACKED (10 bit) .....23
    - 7.2.4 GVSP\_PIX\_MONO12 (12 bit) .....23
    - 7.2.5 GVSP\_PIX\_MONO12\_PACKED (12 bit) .....23
  - 7.3. Bit Allocation (Pixel Format / Pixel Type) - BB-141GE (Bayer mosaic color) .....23
    - 7.3.1 GVSP\_PIX\_BAYRG8 “BayerRG8” .....23
    - 7.3.2 GVSP\_PIX\_BAYRG10 “Bayer RG10”.....23
    - 7.3.3 GVSP\_PIX\_BAYRG12 “Bayer RG12” .....24
    - 7.3.4 GVSP\_PIX\_BAYGB8 “Bayer GB8”.....24
    - 7.3.5 GVSP\_PIX\_BAYGB10 “Bayer GB10” .....24
    - 7.3.6 GVSP\_PIX\_BAYGB12 “Bayer GB12” Odd Line.....24
- 8. Functions and Operations ..... 26
  - 8.1. GigE Vision Standard Interface .....26
  - 8.2. Recommended Network Configurations.....26
    - 8.2.1 Verified Network Interface Cards (NICs) .....26
    - 8.2.2 Video data rate (network bandwidth) .....27
    - 8.2.3 Disable Firewalls .....30
    - 8.2.4 Enabling Jumbo Frames .....30
    - 8.2.5 Setting Receive Descriptors.....32
    - 8.2.6 Interrupt Moderation rate.....33
    - 8.2.7 Calculating and setting Inter-Packet Delay .....33
    - 8.2.8 Confirm the Filter Driver is used .....34

## BM-141GE, OP22-5-1 / BB-141GE, OP22-5-1

---

8.2.9	Others.....	35
8.2.10	Note for 100BASE-TX connection.....	35
8.3.	Basic functions.....	36
8.3.1	Vertical Binning (BM-141GE only).....	36
8.3.2	BB-141GE. Bayer mosaic filter.....	37
8.3.3	Partial Scanning (fixed and variable).....	37
8.3.4	Decimation Readout (Draft) mode (BB-141GE only).....	39
8.3.5	Electronic Shutter.....	39
8.3.6	Auto-Iris Lens video output (12-pin Hirose connector).....	41
8.3.7	Full Auto Exposure mode.....	41
8.3.8	Auto-detect LVAL-sync / async accumulation.....	42
8.3.9	Rear panel indicator.....	43
8.4.	Pre-process functions.....	43
8.4.1	Bayer White Balance (BB-141GE only).....	44
8.4.2	Automatic Gain Control.....	44
8.4.3	Programmable Look UP table (LUT).....	44
8.4.4	Blemish Compensation circuit.....	45
8.4.5	Extended temperature operation (-45 °C to +65 °C).....	45
8.5.	Sensor Layout and timing.....	46
8.5.1	CCD Sensor Layout.....	46
8.5.2	Horizontal timing.....	47
8.5.3	Vertical timing.....	47
8.5.4	Partial Scanning.....	48
8.5.5	Vertical binning.....	49
8.5.6	Draft mode.....	50
8.6.	Operation Modes.....	51
8.6.1	Continuous Mode.....	51
8.6.2	Edge Pre-Select (EPS) Trigger Mode.....	52
8.6.3	Pulse Width Control (PWC) Trigger Mode.....	53
8.6.4	Reset Continuous Trigger (RCT) Mode.....	55
8.6.5	Smearless EPS Trigger Mode.....	56
8.6.6	Sequential Trigger Mode (EPS).....	57
8.6.7	Delayed Readout EPS and PWC Modes (EPS and PWC).....	58
8.6.8	Optical Black Transfer Mode.....	59
8.6.9	Multi ROI Mode (Multi Region of Interest).....	60
8.7.	Operation Mode and Functions matrix.....	60
8.8.	Special notes for settings.....	61
8.8.1	When the image size is changed.....	61
8.8.2	When the image is captured.....	61
8.8.3	Acquisition frame rate.....	61
9.	Register Map.....	62
10.	External Appearance and Dimensions.....	71
11.	Specifications.....	72
11.1	Spectral response.....	72
11.2	Specification table.....	73
12.	Appendix.....	75
12.1.	Precautions.....	75
12.2.	Typical Sensor Characteristics.....	75
12.4.	Exportation.....	76
12.5.	References.....	76
	Change History.....	78
	User's Record.....	79

---



## 1. General

*This manual covers the digital monochrome progressive scan camera BM-141GE, OP22-5-1 and color progressive scan camera BB-141GE, OP22-5-1*

The BM-141GE, OP22-5-1 and BB-141GE, OP22-5-1 are GigE Vision compliant cameras offering 1.4 megapixel resolution and a “B Series” cubic form factor. The OP22-5-1 designations indicate that the cameras have been certified for operation across an extended temperature range of -40°C to +65°C, making them capable of withstanding harsh field environments. For simplicity, the remainder of this manual will typically refer to the cameras without the OP22-5-1 suffixes.

Both the monochrome version BM-141GE and the color version BB-141GE provide a frame rate of 30 frames/second at full resolution. Using vertical binning (BM-141GE only), draft mode (BB-141GE only) or partial scan, the camera can achieve faster frame rates. The 2/3" CCD (ICX285) with square pixels offers superb sensitivity and image quality. The high-speed shutter function and asynchronous random trigger mode allows the camera to capture high quality images of fast moving objects.

The color version BB-141GE incorporates a primary RGB Bayer mosaic filter on the CCD to output raw Bayer images. The JAI GigE Vision SDK and Control Tool software provides color interpolation to display or save color images. The camera features built-in white balance, eliminating the need for performing this function on the host-PC.

The BM-141GE/BB-141GE also complies with the GenICam standard, including the Standard Feature Naming Convention (SFNC) as it has an internal XML file that is used to describe the functions/features of the camera. For further information on GenICam and SFNC, please go to [www.emva.org](http://www.emva.org)

As an application programming interface, JAI provides an SDK (Software Development Kit). This SDK includes GigE Vision Filter Driver, JAI control tool, software documentation and code examples. The JAI SDK and the latest version of this manual can be downloaded from [www.jai.com](http://www.jai.com). For camera revision history, please contact your local JAI distributor.

## 2. Camera nomenclature

The standard camera composition consists of the camera main body and C-mount protection cap. The camera is available in the following versions:

### **BM-141GE**

Where **B** stands for "B-series" form factor, **M** stands for monochrome, 141 represents the resolution "1.4 million pixels", **141** indicates that it is the first variant with the same resolution as a prior model, **GE** stands for "GigE Vision" interface, and **OP22-5-1** indicates extended temperature operation.

### **BB-141GE**


Where **B** stands for "B-series" form factor, **B** stands for Bayer color, **141** represents the resolution "1.4 million pixels", **141** indicates that it is the first variant with the same resolution as a prior model, **GE** stands for "GigE Vision" interface, and **OP22-5-1** indicates extended temperature operation.

### **3. Main Features**

- 1.4-megapixel digital video camera
- Certified for extended temperature operation (-40°C to +65°C)
- GigE vision and GenICam SFNC compliant
- 1392 (h) x 1040 (v) resolution
- 6.45  $\mu\text{m}$  square pixels
- 2/3 inch progressive scan - Monochrome and Bayer mosaic color versions
- 30.12 frames/second with full resolution in continuous operation
- 30 frames/second with external trigger and full resolution
- Increased frame rate with vertical binning (BM-141GE only) , draft mode(BB-141GE only) and fixed or variable partial scan
- Full auto exposure mode linking auto gain, auto shutter, and auto iris functions
- Preset and auto shutter modes provided
- Exposure time from 63 $\mu\text{s}$  to 2 sec. using Pulse Width trigger mode
- Programmable exposure from 63 $\mu\text{s}$  to 33 ms in Full Frame scan
- GPIO in combination with Pulse width trigger for more precise exposure time
- Sequencer trigger mode for on-the -fly change of gain, exposure and ROI
- Edge pre-select, pulse width control and reset continuous trigger modes
- One-push, preset, manual or auto Bayer white balance for BB-141GE
- Manual and automatic gain control
- Look Up Table (LUT) for gamma and knee settings
- Blemish Compensation circuit built in
- LVAL-synchronous/-asynchronous operation (auto-detect)
- Auto iris lens video output (can be selected by DIP switch)
- GigE Vision interface with 12, 10 or 8-bit output
- Programmable GPIO with opto-isolated inputs and outputs
- Flange back adjustment mechanism provided
- Comprehensive software tools and SDK for Windows XP/Vista/7 - 32-bit (x86) and 64-bit (x64)

## 4. Locations and Functions

### 4.1. Locations and functions



- |  |   |
|--|---|
| <ul style="list-style-type: none"> <li>1. Lens mount</li> <li>2. CCD sensor</li> <li>3. Flange back fixed screws</li> <li>4. 12-pin connector</li> <li>5. D-sub 9 pin connector</li> <li>6. RJ-45</li> <li>7. LED</li> <li>8. LED</li> <li>9. LED</li> <li>10. Holes for RJ-45 thumbscrews</li> <li>11. Holes for RJ-45 thumbscrews</li> <li>12. Mounting holes</li> </ul> | <p>C-mount (Note *1)<br/>                 2/3 inch CCD sensor<br/>                 Fix the ring after flange back adjustment</p> <p>DC +12V power and GPIO interface<br/>                 Auxiliary GPIO interface (LVDS IN and TTL IN/OUT)</p> <p>GigE Vision I/F. Accepts connector w thumbscrews.<br/>                 Indication for power and trigger</p> <p>GigE Network condition: LINK<br/>                 GigE Network condition: ACT</p> <p>Horizontal type (left and right of RJ-45) (Note *2)<br/>                 Vertical type (above and below RJ-45). (Note*2)<br/>                 M3 depth 5 mm for tripod mount plate (Note *3)</p> |
|--|---|

- \*1) Note: Rear protrusion on C-mount lens must be less than 10.0mm.
- \*2) Note: When an RJ-45 cable with thumbscrews is connected to the camera, please do not excessively tighten screws by using a screwdriver. The RJ-45 receptacle on the camera might be damaged.  
 For security, the strength to tighten screws is less than 0.291 Newton meter (Nm). Tightening by hand is sufficient in order to achieve this.
- \*3) Note: The tripod adapter plate MP-41 can be used with BM/BB-141GE

Fig. 1. Locations

## 4.2. Flange back adjustment



1. Attach the C mount lens to the camera (①).
2. Under the actual environment and the actual distance to the object, check whether it is possible to focus the lens by rotating the focus ring of the lens.
3. If it does not focus, loosen the two flange back fixed screws (③).
4. Set the focus ring indication in accordance with the distance to the object, for instance, 1 m.




5. Under this condition, rotate the lens. As the flange back adjustment ring is simultaneously rotated, set the ring so as to focus the lens (①).
6. At that position, tighten the two flange back fixed screws (③).

## 5. Pin Assignment

### 5.1 12-pin Multi-connector (DC-in/GPIO/Iris Video)

Type: HR10A-10R-12PB  
(Hirose) male.  
(Seen from the rear of camera)




Pin no.	Signal	Remarks
1	GND	
2	+12 V DC input	
3	Opt IN 2 (-) / GND (*1)	GPIO IN / OUT
4	Opt IN 2 (+)/Iris Video out (*1)	
5	Opt IN 1 (-)	
6	Opt IN 1 (+)	
7	Opt Out 1 (-)	
8	Opt Out 1 (+)	
9	Opt Out 2 (-)	
10	Opt Out 2 (+)	
11	+ 12 V DC input	
12	GND	

Fig. 2. 12-pin connector.

\*1: Iris Video output function can be set by the internal DIP switch (SW601).

### 5.2 Digital Output Connector for Gigabit Ethernet

Type: RJ-45 : HFJ11-1G02E-L21RL or equivalent




The digital output signals follow the Gigabit Ethernet interface using RJ-45 conforming connector. The following is pin assignment for Gigabit Ethernet connector.

Pin No	In/Out	Name
1	In/Out	MX1+ (DA+)
2	In/Out	MX1- (DA-)
3	In/Out	MX2+ (DB+)
4	In/Out	MX3+ (DC+)
5	In/Out	MX3- (DC-)
6	In/Out	MX2- (DB-)
7	In/Out	MX4+ (DD+)
8	In/Out	MX4- (DD-)

Fig. 3. Gigabit Ethernet connector

### 5.3 D-sub 9 pin connector for GPIO (Auxiliary)



Type: DD-09SSG

No	I/O	Name	Note
1	I	LVDS In1-	
2	I	LVDS In1+	
3	I	TTL IN 1	75ohm Terminator *
4	O	TTL Out 1	
5		GND	
6		NC	
7		NC	
8	O	TTL Out 2	
9		GND	

Fig. 4 D-sub 9 pin connector


\*Can be changed by internal DIP switch (SW600)

#### 5.4 Internal DIP switch

In order to change, the top cover must be removed.

**SW601** For selection of OPT IN and  
Iris Video OUT


Factory default is UP position (OPT IN).  
To select an Iris video, these two  
switches should be set at DOWN.



Left side, as seen from the  
lens side

**SW600** For selection of TTL IN 1 75  
ohm ON or OFF

Factory default is UP position (75 ohm  
OFF). To set 75 ohm ON, these two  
switches must be DOWN.




Right side, as seen from the  
lens side

## 6. GPIO (Inputs and outputs)

### 6.1. Overview

All input and output signals pass through the GPIO (General Purpose Input and Output) module. The GPIO module consists of a Look-Up Table (LUT - Cross-Point Switch), 2 Pulse Generators and a 12-bit counter. In the LUT, the relationship between inputs, counters and outputs is governed by internal register set-up.



Some of the descriptions in this diagram differ from the display in the camera control tool. The following table shows display name and description.

Line Source		Line Selector	
Description	Display Name	Description	Display Name
OPT IN 1	GPIO Port In 1	TTL OUT 1	GPIO Port 1
OPT IN 2	GPIO Port In 2	TTL OUT 2	GPIO Port 2
TTL IN 1	GPIO Port In 3	OPT OUT 1	GPIO Port 3
LVDS IN 1	GPIO Port In 4	OPT OUT 2	GPIO Port 4

On the above block diagram, Trigger 0 is used for Exposure and Trigger 1 is used for Delayed Readout. The Time Stamp Reset can reset the time stamp compliant with GigE Vision standard. This is used for ensuring the same time stamp if multiple cameras are used.

The blocks shown in the above diagram have the following functionalities:

### 6.1.1 LUT (Cross Point Switch)

The LUT works as a cross-point switch which allows connecting inputs and outputs freely. The signals LVAL\_IN, DVAL\_IN, FVAL\_IN and EEN\_IN all originate from the camera timing circuit. On this diagram, Trigger 0 is used for exposure and Trigger 1 is used for Delayed Readout. The Time Stamp Reset signal can reset the time stamp specified in GigE Vision Format. This signal can be used when time stamps from several cameras connected are coincident with each other.

Outputs from LUT described in the blue line block shows GPIO settings for LINE SELECTOR on JAI Camera Control tool and inputs for LUT on the left side shows GPIO settings for LINE SOURCE on JAI Camera Control tool right. Refer to Chapter 6.3 GPIO inputs/Outputs table.

### 6.1.2 12-bit Counter

The camera pixel clock can be used as a source. The counter has a “Divide by N”, where N has the range 1 through 4096, allowing a wide range of clock frequencies to be programmed. Setting Value 0 is bypass, setting value 1 is 1/2 dividing and setting value 4095 is 1/4096 dividing. The pixel clock for BM-141GE/BB-141GE is 58 MHz.

### 6.1.3 Pulse Generators (0 to 1)

Each pulse generator consists of a 19-bit counter. The behavior of these signals is defined by their pulse width, start point and end point.

The pulse generator signals can be set in either triggered or periodic mode.

In triggered mode, the pulse is triggered by the rising edge/falling edge/high level or low level of the input signal. In periodic mode, the trigger continuously generates a signal that is based on the configured pulse width, starting point and end point.

Each pulse generator operates at the frequency created in the 12-bit counter. As the pixel clock (58 MHz) is used as the main frequency, the frequency of pulse generator is 58MHz to 31.693 KHz.

## 6.2 Opto-isolated Inputs/Outputs

The control interface of the C3 GigE Vision camera series has opto-isolated inputs and outputs, providing galvanic separation between the camera's inputs/outputs and peripheral equipment. In addition to galvanic separation, the opto-isolated inputs and outputs can cope with a wide range of voltages; the voltage range for inputs is +3.3V to +24V DC whereas outputs will handle +5V to +24V DC.




Fig.5. Photo coupler



6.2.1 Recommended External Input circuit diagram for customer




Fig.6. External Input Circuit, OPT IN 1 and 2

6.2.2 Recommended External Output circuit diagram for customer





Fig.7. External Output Circuit, OPT OUT 1 and 2

6.2.3 Optical Interface Specifications

The relation of the input signal and the output signal through the optical interface is as follows.



## BM-141GE, OP22-5-1 / BB-141GE, OP22-5-1

Conditions for Input	
Input Line Voltage Range	+3.3V ~ +24V
Input Current	6mA ~ 30mA
Minimum Input Pulse Width to Turn ON	0.5μs

Output Specifications	
Output Load(Maximum Current)	100mA
Minimum Output Pulse Width	20μs
Time Delay Rise TDR	0.5μs ~ 0.7μs
Rise Time RT	1.2μs ~ 3.0μs
Time Delay Fall TDF	1.5μs ~ 3.0μs
Fall Time FT	4.0μs ~ 7.0μs

Fig.8 Optical Interface Performance

### 6.3. Inputs and outputs table

		Output Ports									
		Trigger 0	Trigger 1	OPT OUT1	OPT OUT2	TTL OUT1	TTL OUT2	Time Stamp Reset	Sequence Reset	Pulse Generator 0	Pulse Generator 1
Input Ports	LVAL IN	x	x	x	x	○	○	x	x	○	○
	DVAL IN	x	x	x	x	○	○	x	x	○	○
	FVAL IN	x	x	x	x	○	○	x	x	○	○
	EEN IN	x	x	○	○	○	○	x	x	○	○
	OPT IN 1	○	○	○	○	○	○	○	○	○	○
	OPT IN 2	○	○	○	○	○	○	○	○	○	○
	TTL IN	○	○	○	○	○	○	○	○	○	○
	LVDS IN	○	○	○	○	○	○	○	○	○	○
	Soft Trigger 0	○	○	○	○	○	○	○	○	○	○
	Soft Trigger 1	○	○	○	○	○	○	○	○	○	○
	Soft Trigger 2	○	○	○	○	○	○	○	○	○	○
	Soft Trigger 3	○	○	○	○	○	○	○	○	○	○
	Pulse Gen. 0	○	○	○	○	○	○	○	○	x	○
	Pulse Gen. 1	○	○	○	○	○	○	○	○	○	x

LEGEND: ○ = valid combination / x = Not valid (do not use this combination)  
 The shaded parts are for the interface to external equipment.


## 6.4. Configuring the GPIO module (register settings)

### 6.4.1 Input /Output Signal Selector


Address	Internal Name	GenICam Name	Access	Size	Value (Range)
0xB060	Selector CAMERA TRIGGER 0 ( for Camera Trigger )	Camera Trigger 0	R/W	4	GPIO Selector: <u>Line Source ( SDK )</u> 0x00:CAMERA LVAL IN 0x01:CAMERA DVAL IN 0x02:CAMERA FVAL IN 0x03:CAMERA EEN IN 0x04:OPT 1 IN 0x05:OPT 2 IN 0x06:TTL 1 IN 0x07:LVDS 1 IN 0x0C:SOFT TRIG 0 0x0D:SOFT TRIG 1 0x0E:SOFT TRIG 2 0x0F:SOFT TRIG 3 0x10:Pulse Generator 0 0x11: Pulse Generator 1 0x7F: No connect
0xB064	Selector CAMERA Trigger 1 ( For Delayed Trigger )	Camera Trigger 1	R/W	4	
0xB070	Selector GPIO PORT 1	GPIO_Port1	R/W	4	
0xB074	Selector GPIO PORT 2	GPIO_Port2	R/W	4	
0xB090	Pulse Generator 0 Selector	PulseGenerator 0	R/W	4	
0xB094	Pulse Generator 1 Selector	PulseGenerator 1	R/W	4	
0xB0A0	Selector Time Stamp Reset	TimeStamp Reset	R/W	4	
0xB0A4	Selector Sequence Table Reset	Sequence Table reset	R/W	4	<u>Line selector (SDK)</u> 0x00:CAMERA Trigger 0 0x01:CAMERA Trigger 1 0x04:TTL OUT 1 0x05:TTL OUT 2 0x06:OPT OUT 1 0x07:OPUOUT 2 0x0C:Pulse Generator 0 0x0D:Pulse Generator 1 0x10:Time stamp reset 0x11:Sequence table reset 0x7F: No connect  Add 0x80 will result in low active output.

The following figures show how to set in the JAI SDK Camera Control Tool.


#### Line Selector



Line Source



Line Polarity




6.4.2 12-bit counter

Address	Internal Name	GenICam Name	Access	Size	Value (Range)
0xB000	Counter Clock Choice	ClockSource	R/W	4	0x01: Pixel Clock
0xB004	Counter Dividing Value	ClockPreScaler	R/W	4	0x000: Bypass 0x001: 1/2 Dividing 0x002: 1/3 Dividing   0xFFFF: 1/4096 Dividing


### 6.4.3 Pulse generators (19 bit x 2)

There are 2 pulse generators (designated 0 through 1) that can be used to create various timing scenarios by programming start point, endpoint, length and repeats.




The following drawing is an example of settings.

FVAL is used for the input of a pulse generator 0 and the clock after the rising edge of FVAL counts 100 clocks for the high period of the pulse and 102 clocks for the pulse length. As 2400 is for Clock Pre-scaler, the output of 12 bit counter is 25 KHz, which is 40µs. The pulse generator 0 creates a 4 ms pulse.



The following shows how to set the pulse generators in the JAI SDK Camera Control Tool.



**BM-141GE, OP22-5-1 / BB-141GE, OP22-5-1**

Address	Internal Name	GenICam name	Access	Size	Value (range)
0xB008	Length Counter 0	Pulse Generator Length	R/W	4	0x00001 to 0xFFFFF
0xB00C	Start point Counter 0(1)	PulseGenerator StartPoint	R/W	4	0x00000 to 0xFFFFF
0xB010	Start point Counter 0(2)	PulseGenerator RepeatCount	R/W	4	0x00: infinite 0x01: 1 time   0xFF: 255 times
0xB014	End point Counter 0	PulseGenerator EndPoint	R/W	4	0x00001 to 0xFFFFF
0xB018	Counter Clear 0	PulseGenerator Clear	R/W	4	0x00: Free Run 0x01: High Level Clear 0x02: Low Level Clear 0x04: Rising Edge Clear 0x08: Falling Edge Clear
0xB01C	Length Counter 1	Pulse Generator Length	R/W	4	0x00001 to 0xFFFFF
0xB020	Start point Counter 1(1)	PulseGenerator StartPoint	R/W	4	0x00000 to 0xFFFFF
0xB024	Start point Counter 1(2)	PulseGenerator RepeatCount	R/W	4	0: Infinite 1: 1 time   255: 255 times
0xB028	End point Counter 1	PulseGenerator EndPoint	R/W	4	0x00001 to 0xFFFFF
0xB02C	Counter 1 Clear	PulseGenerator Clear	R/W	4	0x00: Free Run 0x01: High Level Clear 0x02: Low Level Clear 0x04: Rising Edge Clear 0x08: Falling Edge Clear

## 6.5. GPIO programming examples

### 6.5.1 GPIO Plus PWC shutter

Example: 10µs unit pulse width exposure control (PWC).

Pixel clock is 58MHz. 580 clocks (680-100) equal 10µs.

	Address	Register	Value
	0xA040	Trigger Mode	2 = PWC (Pulse Width Control)
①	0xB090	Pulse Generator 0 Selector	4 =OPT IN 1
②	0xB000	Clock Choice	1 = Pixel Clock (60MHz)
	0xB004	Counter Dividing Value	0 = Pass through
	0xB008	Length Counter 0	1000 Clocks
	0xB00C	Start point Counter 0(1)	100 Clocks
	0xB010	Start point Counter 0(2)	1
	0xB014	End point Counter 0	680 Clocks
	0xB018	Counter Clear 0	4 = Rising Edge Clear
③	0xB060	CAMERA TRIGGER Selector	16 = pulse generator 0
①	0xB090	Pulse Generator 0 Selector	4 =OPT IN 1




Fig.9 Pulse Generator Timing Example 1

6.5.2 Internal Trigger Generator

Example: Create a trigger signal and trigger the camera

	Address	Register	Value
	0xA040	Trigger Mode	1 = EPS
①	0xB000	Clock Choice	1 = Pixel Clock
	0xB004	Counter Dividing Value	1829= 1/1830(Line Rate)
	0xB008	Length Counter 0	1000 Clocks
	0xB00C	Start point Counter 0 (1)	100 Clocks
	0xB010	Start point Counter 0 (2)	0 = Infinite
	0xB014	End point Counter 0	500 Clocks
	0xB018	Counter Clear 0	0 = Free Run
②	0xB060	CAMERA TRIGGER Selector	16 = pulse generator 0





Fig.10 Pulse Generator 0 timing Example 2



## 7. GigE Vision Streaming Protocol (GVSP)


### 7.1. Digital Video Output (Bit Allocation)

Although the BM-141GE and BB-141GE are digital cameras, the image is generated by an analog component, the CCD sensor.

The table and diagram below show the relationship between the analog CCD output level and the digital output.

CCD out	Analog Signal *	Digital Out		
		8 bit	10 bit	12 bit
Black	Setup 3.6%, 25mV	8 LSB	32 LSB	128 LSB
200mV	700mV	222 LSB	890 LSB	3560 LSB
230mV	800mV	255 LSB	1023 LSB	4095 LSB

The standard setting for 10-bit video level is 890 LSB. 200 mV CCD output level equals 100% video output.



**Important Note:**

When gain is set at -4.5db to -6dB, the linearity of the video output may deteriorate around 100% video output level. Please confirm the output level characteristics when -4.5db to -6dB gain is set.

Fig. 11. Digital Output (10-bit output)

### 7.2. Bit Allocation (Pixel Format / Pixel Type) - BM-141GE (monochrome)

In the GigE Vision Interface, GVSP (GigE Vision Streaming Protocol) is used for an application layer protocol relying on the UDP transport layer protocol. It allows an application to receive image data, image information and other information from a device.

In the BM-141GE monochrome camera, the following pixel types supported by GVSP are available. With regard to the details of GVSP, please refer to the GigE Vision Specification available from AIA ([www.machinevisiononline.org](http://www.machinevisiononline.org)).

#### 7.2.1 GVSP\_PIX\_MONO8 (8bit)

1 Byte								2 Byte								3 Byte							
Y0								Y1								Y2							
0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7

#### 7.2.2 GVSP\_PIX\_MONO10 (10bit)

1 Byte								2 Byte								3 Byte								4 Byte							
Y0								Y0								Y1								Y1							
0	1	2	3	4	5	6	7	8	9	X	X	X	X	X	X	0	1	2	3	4	5	6	7	8	9	X	X	X	X	X	X

## BM-141GE, OP22-5-1 / BB-141GE, OP22-5-1

### 7.2.3 GVSP\_PIX\_MONO10\_PACKED (10 bit)

1 Byte                                      2 Byte                                      3 Byte                                      4 Byte

Y0										Y1										Y2										Y3																	
2	3	4	5	6	7	8	9	0	1	X	X	0	1	X	X	2	3	4	5	6	7	8	9	2	3	4	5	6	7	8	9	0	1	X	X	0	1	X	X	2	3	4	5	6	7	8	9

### 7.2.4 GVSP\_PIX\_MONO12 (12 bit)

1 Byte                                      2 Byte                                      3 Byte                                      4 Byte

Y0								Y0								Y1								Y1							
0	1	2	3	4	5	6	7	8	9	10	11	X	X	X	X	0	1	2	3	4	5	6	7	8	9	10	11	X	X	X	X

### 7.2.5 GVSP\_PIX\_MONO12\_PACKED (12 bit)

1 Byte                                      2 Byte                                      3 Byte                                      4 Byte

Y0												Y1												Y2												Y3											
4	5	6	7	8	9	10	11	0	1	2	3	0	1	2	3	4	5	6	7	8	9	10	11	4	5	6	7	8	9	10	11	0	1	2	3	0	1	2	3	4	5	6	7	8	9	10	11

Address	Internal Name	Access	Size	Value
0xA410	Pixel Format type	R/W	4	0x01080001:Mono8 0x01100003:Mono10 0x010C0004:Mono10 Packed 0x01100005:Mono12 0x010C0006:Mono12 Packed

## 7.3. Bit Allocation (Pixel Format / Pixel Type) - BB-141GE (Bayer mosaic color)

In the GigE Vision Interface, GVSP (GigE Vision Streaming Protocol) is used for an application layer protocol relying on the UDP transport layer protocol. It allows an application to receive image data, image information and other information from a device.

In the BB-141GE color camera, the following pixel types supported by GVSP are available. With regard to the details of GVSP, please refer to the GigE Vision Specification available from AIA.

### 7.3.1 GVSP\_PIX\_BAYRG8 “BayerRG8”

Odd Line

1 Byte                                      2 Byte                                      3 Byte

R0								G1								R2							
0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7

Even Line

1 Byte                                      2 Byte                                      3 Byte

G0								B1								G2							
0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7

### 7.3.2 GVSP\_PIX\_BAYRG10 “Bayer RG10”

Odd Line

1 Byte                                      2 Byte                                      3 Byte                                      4 Byte

R0								R0								G1								G1							
0	1	2	3	4	5	6	7	8	9	X	X	X	X	X	X	0	1	2	3	4	5	6	7	8	9	X	X	X	X	X	X

Even Line

1 Byte                                      2 Byte                                      3 Byte                                      4 Byte

G0								G0								B1								B1							
0	1	2	3	4	5	6	7	8	9	X	X	X	X	X	X	0	1	2	3	4	5	6	7	8	9	X	X	X	X	X	X

**7.3.3 GVSP\_PIX\_BAYRG12 “Bayer RG12”**

Odd Line

1 Byte								2 Byte				3 Byte				4 Byte															
R0								R0				G1				G1															
0	1	2	3	4	5	6	7	8	9	10	11	X	X	X	X	0	1	2	3	4	5	6	7	8	9	10	11	X	X	X	X

Even Line

1 Byte								2 Byte				3 Byte				4 Byte															
G0								G0				B1				B1															
0	1	2	3	4	5	6	7	8	9	10	11	X	X	X	X	0	1	2	3	4	5	6	7	8	9	10	11	X	X	X	X

**7.3.4 GVSP\_PIX\_BAYGB8 “Bayer GB8”**

Odd Line

1 Byte								2 Byte				3 Byte											
G0								B1				G2											
0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7

Even Line

1 Byte								2 Byte				3 Byte											
R0								G1				R2											
0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7

**7.3.5 GVSP\_PIX\_BAYGB10 “Bayer GB10”**

Odd Line

1 Byte								2 Byte				3 Byte				4 Byte															
G0								G0				B1				B1															
0	1	2	3	4	5	6	7	8	9	X	X	X	X	X	X	0	1	2	3	4	5	6	7	8	9	X	X	X	X	X	X

Even Line

1 Byte								2 Byte				3 Byte				4 Byte															
R0								R0				G1				G1															
0	1	2	3	4	5	6	7	8	9	X	X	X	X	X	X	0	1	2	3	4	5	6	7	8	9	X	X	X	X	X	X

**7.3.6 GVSP\_PIX\_BAYGB12 “Bayer GB12” Odd Line**

1 Byte								2 Byte				3 Byte				4 Byte															
G0								G0				B1				B1															
0	1	2	3	4	5	6	7	8	9	10	11	X	X	X	X	0	1	2	3	4	5	6	7	8	9	10	11	X	X	X	X

Even Line

1 Byte								2 Byte				3 Byte				4 Byte															
R0								R0				G1				G1															
0	1	2	3	4	5	6	7	8	9	10	11	X	X	X	X	0	1	2	3	4	5	6	7	8	9	10	11	X	X	X	X

## BM-141GE, OP22-5-1 / BB-141GE, OP22-5-1

---

Address	Internal Name	Access	Size	Value
0xA410	Pixel Format type	R/W	4	0x01080009:BAYRG8 0x0108000A:BAYGB8 0x0110000D:BAYRG10 0x0110000E:BAYGB10 0x01100011:BAYRG12 0x01100012:BAYGB12

Note: BB-141GE has the same Bayer sequence for full and any partial scanning as RG. Therefore, comparing full scanning and partial scanning, the center might be shifted. BB-141GE supports BAYER GB8, BAYER GB10 and BAYER GB12. When this type is selected, the output starts from 2nd line for all scanning.

## 8. Functions and Operations

### 8.1. GigE Vision Standard Interface

The BM-141GE and BB-141GE are designed in accordance with the GigE Vision standard. Digital images are transmitted over Cat5e or Cat6 Ethernet cables. All camera functions are also controlled via the GigE Vision interface.

The camera can operate in continuous mode, providing an endless stream of images. For capturing individual images related to a specific event, the camera can also be triggered. For precise triggering, it is recommended to use a hardware trigger applied to the Hirose 12-pin connector. It is also possible to initiate a software trigger through the GigE Vision interface. However, when using a software trigger, certain latency inherent to the GigE interface must be expected. This latency, which manifests itself as jitter, greatly depends on the general conditions and traffic on the GigE connection. The frame rate described in this manual is for the ideal case and may deteriorate depending on conditions.

When using multiple cameras (going through a switch and/or a single path) or when operating in a system with limited transmission bandwidth the Delayed Readout Mode and Inter-Packet Delay functions can be useful.

### 8.2. Recommended Network Configurations

Although the BM-141GE and BB-141GE conform to Gigabit Ethernet (IEEE 802.3) not all combinations of network interface cards (NICs) and Switches/Routers are suitable for use with the GigE Vision compliant camera. JAI will endeavor to continuously verify these combinations, in order to give users the widest choice of GigE components for their system design.

#### 8.2.1 Verified Network Interface Cards (NICs)

At the time of publishing this document these combinations have been verified:

NIC manufacturer	Model	PCI Bus	PCI-X Bus	PCI-Express Bus
Intel	PRO/1000MT (PWLA8490MT)	√ (33MHz)	√(100MHz)	–
Intel	PRO/1000GT (PWLA8391GT)	√ (33MHz)	√ (33MHz)	–
Intel	PRO/1000PT (EXPI9300PT)	–	–	√ ( x1 )
Intel	Gigabit CT Desktop adaptor (EXPI9301CT)	–	–	√ ( x1 )
Intel	PRO/1000PT Quad port (EXPI9404PT)	–	–	√ ( x4 )
Intel	PRO/1000PT Dual port (EXPI9402PT)	–	–	√ ( x4 )

## BM-141GE, OP22-5-1 / BB-141GE, OP22-5-1

---

Minimum PC requirements are as follows in order to fulfill the above conditions:

- ◆ Intel Core 2 Duo , 2.4 GHz or better
- ◆ At least 2 GB memory
- ◆ Video Card with PCI Express Bus x 16, VRAM better than DDR2 with 256 MB or more, and display capability of 2560 x 1600
- ◆ Windows XP, SP2 (32bit)
- ◆ Functions such as screen saver and power save should not be used. Unnecessary applications such as Word, Excel or others should not be used.

**Note:** Pentium 4 type PC is not recommended due to dependency on chip set bus performance.

### 8.2.2 Video data rate (network bandwidth)

The video bit rates for BM-141GE and BB-141GE in continuous mode are:

Model	Pixel Type	Packet data volume (based on a packet size of 1428)
BM-141GE	MONO8	362 Mbit/s
	MONO10_PACKED MONO12_PACKED	544 Mbit/s
	MONO10 MONO12	725 Mbit/s
	BAYRG8,BAYGB8	362 Mbit/s
BB-141GE	BAYRG10,BAYBG10 BAYRG12,BAYGB12	725 Mbit/s

- ◆ In the case of using Jumbo Frames, the packet data will be improved by 2%.
- ◆ For BM-141GE and BB-141GE, the jumbo frame size can be a maximum of 16384 Bytes (factory setting is 1428 Bytes). The NIC must also be set to support Jumbo Frames (see section 8.2.4).
- ◆ Based on Pixel Type, the packet size may be automatically adjusted inside the camera to its most suitable value .

To ensure the integrity of packets transmitted from the camera, it is recommended that these simple guidelines be followed:

1. Whenever possible use a peer-to-peer network.
2. When connecting several cameras, going through a network switch, make sure it is capable of handling jumbo packets and that it has sufficient memory capacity.
3. Configure inter-packet delay to avoid congestion in networks switches.
4. Disable screen saver and power save functions on computers.
5. Use high performance computers with multi-CPU, hyper-thread and 64-bit CPU, etc.
6. Only use Gigabit Ethernet equipment and components together with the camera.
7. Use at least Cat5e and preferably Cat6 Ethernet cables.
8. Whenever possible, limit the camera output to 8-bit.

◆ **Note for setting packet size**

The packet size is set to 1428 as the factory default. Packet size can be modified in the GigE Vision Transport Layer Control section of the camera control tool (see below). For BM-141GE and BB-141GE, users may enter any value for the packet size and the value will be internally adjusted to an appropriate, legal value that complies with the GenICam standard. Thus, the actual packet size may be different than the value entered by the user.

Caution: do not set the packet size larger than the maximum setting available in the NIC or switch to which the camera is connected (see section 8.2.4). Doing so will cause output to be blocked.



Regarding data transfer rate, a larger packet size produces a slightly lower data transfer rate. BM-141GE and BB-141GE can support a maximum of 16384 byte packets provided the NIC being used has a Jumbo Frames function with a setting of a 16384 bytes or larger.

◆ **Note for calculation of Data Transfer Rate**

**Setting parameter**

Item	Unit	Symbol
Image Width	[pixels]	A
Image Height	[pixels]	B
Bits per Pixel	[bits]	C
Frame Rate	[fps]	D
Packet Size	[Bytes]	E
Number of Packets (including Data Leader & Trailer Packet)	[packets]	G
Data Transfer Rate	[Mbit/s]	J

**Fixed value**

Item	Unit	value
Data Leader Packet Size	[Bytes]	90
Data Trailer Packet Size	[Bytes]	62

## BM-141GE, OP22-5-1 / BB-141GE, OP22-5-1

---

### Formula to calculate Data Transfer Rate

$$J = \frac{90 + 62 + (E + 18) * (G - 2) * 8 * D}{1000000}$$

Where,

$$G = \text{ROUNDUP} \left\{ \frac{A * B * C}{8 / (E - 36)} \right\} + 2$$

The following table shows Bits per Pixel (C) which depends on the pixel format.

Pixel format	Bit
MONO8	8
MONO10	16
MONO10Packed	12
MONO12	16
MONO12Packed	12
BAYRG8	8
BAYGR8	8
BAYGB8	8
BAYBG8	8
BAYRG10	16
BAYGR10	16
BAYGB10	16
BAYBG10	16
BAYRG12	16
BAYGB12	16
RGB8	24
BGR8	24
RGB10V1Packed	32
RGB10V2Packed	32

### Calculation example: BM-141GE Pixel type Mono8

Item	Unit	Symbol	Setting
Image Width	[pixels]	A	1392
Image Height	[pixels]	B	1040
Bits per Pixel	[bits]	C	8
Frame Rate	[fps]	D	30.12
Packet Size	[Bytes]	E	1428
Number of Packets (including Data Leader & Trailer Packet)	[packets]	G	
Transfer Data Rate	[Mbit/s]	J	

$$G = \text{ROUNDUP} \left\{ \frac{1392 \times 1040 \times 8}{8 / (1428 - 36)} \right\} + 2 = 1040 + 2 = 1042$$


$$J = \frac{90 + 62 + (1428 + 18) \times (1042 - 2) \times 8 \times 30.12}{1000000} = 362 \text{ Mbit/s}$$



### 8.2.3 Disable Firewalls


To ensure proper functions of the JAI SDK & Control Tool, all firewalls must be disabled. This also includes the Windows firewall.

Click [Start], [Control Panel] for accessing the Windows firewall configuration.




### 8.2.4 Enabling Jumbo Frames

- (1) Click [Start] and click [Control Panel].
- (2) Click [Performance and Maintenance].
- (3) Click [System].
- (4) Click [Hardware] tab.
- (5) Click [Device Manager].




- (6) Expand [Network adapters].
- (7) Select target NIC, right-click, and click [Properties].




Note: Intel(R) 1000 is used in this example.

If different NICs are used, the following setup tabs will likely be different. Follow the tabs associated with the specific NIC used.

(8)Click [Advanced] tab.



(9) Select **Jumbo Frames** under Property, and select **16128** under Value.



(10)Click [OK].


(11)Close [Device Manager].

(12)Close [System Properties] by clicking [OK].

### 8.2.5 Setting Receive Descriptors

If the Network Connection Properties list contains a property called Receive Descriptors, then change its property to the maximum value supported by the NIC installed in the computer.


Click “OK” to save the property.



### 8.2.6 Interrupt Moderation rate


If the Network Connection Properties list contains a property called Interrupt Moderation Rate, then it is possible to set the preferred value. When it is changed from Minimal, to Medium, High and Extreme, the number of interrupts is decreased to get better performance. Set it to “Extreme”.

Click “OK” to save the property.




### 8.2.7 Calculating and setting Inter-Packet Delay

When connecting several cameras to one network interface card via a switching hub, it is important to optimize the Inter-Packet Delay of the cameras to avoid congestion in the switch. A sure sign of congestion is the loss of packets. Since increasing the inter-packet delay also adds overhead to the data transfer, it is important to calculate the optimal setting in order to make best use of the video bandwidth.



The JAI Control Tool has a built in wizard for calculating Inter-Packet Delay. When the Inter-Packet Delay function is activated, a button appears on the right hand side of the bar. Click the button to open the calculation wizard window.







1. Type in the frame rate of the connected camera. BM-141GE and BB-141GE operate at 30 fps.
2. Set the bandwidth at 80%.
3. Click the calculation tab.
4. New value is calculated.
5. Click OK. This shown value is automatically transferred to the Packet Delay column of the Control Tool.

### 8.2.8 Confirm the Filter Driver is used


- ◆ The filter driver is installed as an optional function when JAI SDK is installed. If the filter driver is not installed at that time, it can be installed from All Programs ⇒ JAI SDK ⇒ GigE Vision Filter Driver ⇒ Install GigE Vision Filter Driver.



- ◆ If the Filter Driver is installed properly, the Camera Control Tool indicates “Driver Type Filter Driver” in the Network Interface.



- ◆ If it is not shown, confirm the setting by clicking the “Settings” icon as indicated by the red arrow below.



### 8.2.9 Others

- ◆ IF “Receive Descriptor” is set at its maximum value, picture disturbance may occur due to “Hyper Threading” mode. If that happens, check that “Hyper Threading” is set at OFF. This is set in BIOS.
- ◆ When the image is being captured, if the frame rate is decreased, change the packet size. Each packet contains header data and when the packet size is small, the total data including header information will increase. Depending on the performance of the computer used, the frame rate may be decreased. Confirm the packet size is increased. It can be set in the Camera Control Tool provided in JAI SDK.

### 8.2.10 Note for 100BASE-TX connection

- ◆ In order to use a 100Mbps network, 100BASE-TX and Full Duplex are available. Half Duplex cannot be used.

- ◆ In the case of connecting on 100BASE-TX, the maximum packet size should be 1500 bytes.
- ◆ In the case of connecting on 100BASE-TX, specifications such as frame rate, trigger interval and so on described in this manual cannot be satisfied.

Pixel Type	Frame rate at Full Frame scan[fps]
MONO8, BAYRG8, BAYGB8	8.0 ~ 8.2
MONO10_PACKED, MONO12_PACKED	5.4 ~ 5.6
MONO10, MONO12, BAYRG10, BAYGB10, BAYRG12, BAYGB12	4.0 ~ 4.2

### 8.3. Basic functions

The BM-141GE and BB-141GE cameras are progressive scan cameras with 12, 10 or 8-bit video output in Gigabit Ethernet. The camera has 1/2, 1/4 or 1/8 partial scanning for faster frame rates. Vertical binning (monochrome) and Draft (color) modes are also available.

The camera can operate in continuous mode as well as in 6 triggered modes:

- Edge Pre-Select Trigger (EPS)
- Pulse Width Control Trigger (PWC)
- Reset Continuous Trigger (RCT)
- Smearless EPS Trigger (EPS)
- Sequential EPS Trigger (EPS)
- Delayed readout EPS Trigger (EPS)
- Delayed readout PWC Trigger (PWC)

Depending on the timing of the trigger input in relationship to FVAL (camera internal frame valid clock), the start of exposure can be immediate (no-delay, LVAL asynchronous) or delayed until next LVAL (LVAL synchronous). In the following sections, the functions are described in detail.

#### 8.3.1 Vertical Binning (BM-141GE only)

The binning function can be used to achieve a higher frame rate or higher sensitivity. The drawback is lower resolution.

Vertical binning is done by adding the charge from pixels in adjacent lines in the horizontal CCD register. Figure12 shows the vertical binning principle.




Fig.12. BM-141GE Vertical binning.

## BM-141GE, OP22-5-1 / BB-141GE, OP22-5-1

The BM-141GE has ON or OFF function for Vertical Binning:

Setting	Value for Register address 0xA084	Resolution	Frame rate
Off (no binning)	0x01	1392(h) x 1040(v) pixels	30.12 frames/sec.
2:1 binning	0x02	1392(h) x 520(v) pixels	50.18 frames /sec.

### 8.3.2 BB-141GE. Bayer mosaic filter

BB-141GE is a color camera based on a CCD sensor with a Bayer RGB color mosaic. The color image reconstruction is done in the host PC. The color sequence in the video signal is the same for all scanning formats.

The line readout follows LVAL.  
The first valid pixel is the same timing as DVAL.

The Bayer color sequence starts with:

- RGR for odd line numbers.
- GBG for even line numbers.

Figure 13 shows the timing sequence for the Bayer mosaic read-out for the available scan modes.





Fig.13. Bayer layout for each scanning

### 8.3.3 Partial Scanning (fixed and variable)

The partial scanning function uses the middle of the image vertically to achieve faster frame rates. This is very useful when capturing and inspecting an image which does not require the full image height. BM-141GE/BB-141GE has 4 fixed-size partial scan modes: 2/3, 1/2, 1/4 and 1/8.



In addition to the fixed partial scan modes, BM/BB-141GE has a variable partial scan mode. The start line can be set from the 1st line to the 1025th line and the scanned lines can be set



from 8 lines to 1032 lines. Please note that if an odd line is selected as the start line, the Bayer color sequence is RGR, and if an even line is selected, it is GBG.

◆ **How to calculate total line number and frame rate for variable partial scan mode**

Variable partial scan: The start line setting      1st line to 1025th line  
 Readout height    8 lines to 1032 lines

Total lines = (OB period in the upper part of the frame \* L) + (Fast Dump period in the upper part of the frame \* L) + (Effective image period \* L) + (Fast dump period in the lower part of frame \* L)  
 Where, OB period in the upper part of the frame = 3L

Fast dump period for the upper part       $Roundup \frac{StartlineNo. + 7}{5} + 2$

Fast dump period for the lower part       $Roundup \frac{1039 - EndLineNo.}{5} + 2$

Frame rate (fps) = 1000000 / (Horizontal pixel no. x Pixel clock x Total lines)

Horizontal Pixel number                              1830  
 Pixel clock    17.24138 ns

Calculation example

Read out: 1/2 partial at the center (520L), Stat line (261), End line (780)

OB period in the upper part of the frame      3L

Fast dump period for the upper part =  $(261+7) \div 5 + 2 = 55.6 \rightarrow 56$


Fast dump period for the lower part =  $(1039-780) \div 5 + 2 = 53.8 \rightarrow 54$

Total lines =  $3 + 56 + 520 + 54 = 633$

Frame rate =  $1000000 \div (1830 \times 17.24138 \times 633) = 50.06 \text{ fps}$

**8.3.4 Decimation Readout (Draft) mode (BB-141GE only)**

The BB-141GE color model is equipped with the draft mode instead of a vertical binning function. 2 lines (RG line and GB line) out of every 8 lines in the BB-141GE are thinned out to be read out. The field of the view is not changed but the height of the image is reduced to 1/4. The frame rate is 101.17 frames per a second.



The same for both Monochrome and color

**Fig.14 Draft mode**

**8.3.5 Electronic Shutter**

BM-141GE / BB-141GE have conventional shutter functions as well as the GenICam standard “Exposure Time Abs” function.

**Preset Shutter**

10 preset shutter steps (including OFF) are available. They are: OFF (1/30), 1/60, 1/100, 1/250, 1/500, 1/1,000, 1/2,000, 1/4,000, 1/8,000, 1/10,000 sec. (See the register map in the SDK documentation for details on how to configure this register - 0xA004)

**Programmable Shutter**

It is possible to set the shutter speed in the range of 2L to 1052L by 1L increments using the programmable shutter. When 1052L is set, it is the equivalent of “OFF (1/30)” or 33.19ms in full frame operation. (See the register map included in the SDK documentation for details how to configure this register - 0xA008)

	Minimum Shutter Time 2L	Maximum Shutter Time
Normal	31.551 μs(1L) * 2L = 63.102 μs	31.551 μs * 1052 L ≈ 33.192 ms
V Binning	37.810 μs * 2L = 75.62 μs	37.810 μs * 527 L ≈ 19.926 ms
Draft	36.879 μs * 2L = 73.759 μs	36.879 μs * 268 L ≈ 9.883 ms

**Pulse Width Control**

When this mode is selected, the exposure time is controlled by the width of the trigger pulse. The minimum trigger pulse width is equal to 2L (63μs) and the maximum is 2 seconds.

**Exposure Auto Continuous (Auto Shutter)**

In this mode, the shutter continuously functions in the range of OFF to 1/500 sec.

**Exposure Time Abs (GenICam Standard)**

This is a function specified in the GenICam standard. The shutter speed can be entered as an absolute exposure time in microseconds ( $\mu$ s) in register address 0xA018. The entered absolute time (Time Abs) is then converted to a programmable exposure (PE) value inside the camera.

The formula below shows the relationship between the PE value used by the camera for the different readout modes and the value entered in register 0xA018.

Due to rounding, some discrepancies may occur.

The relation between PE value and Time Abs

Normal readout PE= 2 + INT (Exposure time -63)  $\mu$ s / (1830/58000000)

V Binning readout PE= 2 + INT (Exposure time -75)  $\mu$ s / (2193/58000000)

DRFAT PE= 2 + INT (Exposure time -73)  $\mu$ s / (2139/58000000)

INT means round down.

The following table shows the minimum value and maximum value for each readout mode.

	Minimum value	Maximum Value
Normal Scan	63 .103 $\mu$ s	33192 $\mu$ s
2/3 Partial Scan	63 .103 $\mu$ s	24358 $\mu$ s
1/2 Partial Scan	63 .103 $\mu$ s	19973 $\mu$ s
1/4 Partial Scan	63 .103 $\mu$ s	13410 $\mu$ s
1/8 Partial Scan	63 .103 $\mu$ s	10128 $\mu$ s
V-Binning Scan	75.62 $\mu$ s	19926 $\mu$ s
Draft	73.724 $\mu$ s	9883 $\mu$ s

**GPIO in combination with Pulse Width trigger**

More precise exposure time can be obtained by using GPIO in combination with Pulse Width Control trigger mode. The clock generator and counter can be programmed in very fine increments. For an example, refer to section 6.5.1.

**8.3.6 Auto-Iris Lens video output (12-pin Hirose connector)**

This analog signal is not routed through the GPIO. This signal is available at pin 4 of the 12-pin Hirose connector. It can be used for lens iris control in Continuous mode only.

The signal is taken after the CCD sensor output passes through the gain circuit. The video output is without sync. The signal is 0.7 Vp-p.

To get this signal, the internal DIP switch (SW 601) must be set. Refer to section 5.4.




Fig. 15. Video output circuit.





Fig. 16. Iris Video

**8.3.7 Full Auto Exposure mode**

The Full Auto Exposure mode lets users combine and integrate three automatic exposure functions: Auto Gain Control (AGC), Auto Shutter (EE), and lens Auto Iris. When dealing with widely varying lighting conditions, these automatic functions can be made to work in a coordinated fashion to control exposure for a constant video level output. This function makes the BM-141GE and BB-141GE well-suited for high-end surveillance or situational awareness applications. Users can choose which auto exposure functions are enabled to work together. Note: auto iris capabilities require the use of a video controlled auto-iris lens system (not provided). The lens should be connected while the power to the camera is OFF. The full auto exposure function operates as described below.



Related registers and settings for Full Auto Exposure are shown in the following table.

Register	Display in SDK	Value	Enable setting for FAE
0xA034	Auto iris Lens Control Signal output	0=OFF 1=ON (Default)	1=ON
0xA000	Shutter mode	0= Preset shutter 1=Programmable exposure 2=Exposure TimeAbs 3=Auto shutter	3=Auto shutter (CCD iris)
0xA0B0	AGC select	0=OFF, 1=ON	1=ON

The automatic functions used for Full Auto Exposure can be configured in various ways to support different application requirements. For example, auto gain is useful if the application includes low light situations, though some additional noise may be seen as gain is increased. Auto shutter can handle most typical daylight scenarios, without needing to add the size, expense and potential for mechanical issues of an auto iris lens system. Auto iris lens control can provide a greater range of exposures than auto shuttering, however different iris settings also produce different depths of field (DOF) which may or may not be acceptable for the application.

The table below shows the possible combinations of functions configurable within Full Auto Exposure mode.


Auto gain	Auto shutter	Auto iris	Comments
ON	OFF	OFF	Auto gain for low light. No changes to depth of field or shutter speed. Difficult to handle bright conditions
ON	ON	OFF	Standard ALC (AGC + auto shutter). Wide exposure range with no auto iris lens required.
ON	OFF	ON	Fixed shutter speed with range of exposure via AGC and auto iris.
ON	ON	ON	Full ALC+ for maximum flexibility in balancing exposure, noise, shutter, and depth of field.
OFF	ON	ON	Wide exposure control for bright situations. Fixed gain/noise. Limited low light capability.
OFF	ON	OFF	Auto shutter control only.
OFF	OFF	ON	Auto iris control only.
OFF	OFF	OFF	Manual only. No auto exposure capability.

### 8.3.8 Auto-detect LVAL-sync / async accumulation

This function replaces the manual setting found in older JAI cameras. Whether accumulation is synchronous or asynchronous in relationship to LVAL depends on the timing of the trigger input. When a trigger is received while FVAL is high (during readout), the camera works in

LVAL-synchronous mode, preventing reset feed-through in the video signal. There is a maximum jitter of one LVAL period from issuing a trigger and accumulation start. When a trigger is received while FVAL is low, the camera works in LVAL-asynchronous mode, (no delay) mode.

This applies to both Edge Pre-Select (EPS) trigger mode and Pulse Width Control (PWC) trigger mode.



- (1) In this period camera executes trigger at the next LVAL. (Prevents feed-through noise)
- (2) Avoid trigger at FVAL transition (+/- 1 LVAL period), as the function may randomly switch between “next“ and “immediate“.
- (3) In this period camera executes trigger immediately. (No delay)

Fig. 17. Auto-detect LVAL sync / a-sync accumulation

### 8.3.9 Rear panel indicator.

The rear panel mounted LED provides the following information:

#### Power Trig LED

- Amber: Power connected - initiating
- Steady green: Camera is operating in Continuous mode
- ✱ Flashing green: Camera is receiving an external trigger

#### LINK LED

- Steady green: 1000 Base-T has been connected
- ✱ Flashing green: 100 Base-TX has been connected

#### ACT LED

- ✱ Flashing amber: Network active in communication




Fig.18 Rear Panel

## 8.4. Pre-process functions

BM-141GE/BB-141GE is provided with several pre-processing functions. The output from the camera is selectable to 8, 10 or 12 bits, but video is digitized to 14-bit quantization. The pre-processing functions make use of the 14-bit video. Featured functions are: Bayer color white balance, R/L channel balance, blemish compensation, gain control and LUT (Look Up Table) for Gamma and Knee correction.

### 8.4.1 Bayer White Balance (BB-141GE only)

Normally, the raw Bayer color signals are sent to the host as they are. In the host, the signals are interpolated to generate an RGB image and perform white balance.

In order to offload the host, the BB-141GE can adjust Gr, R, Gb and B levels individually to get the white balance for the Bayer output signal. BB-141GE has manual white balance, one-push auto white balance, continuous auto white balance and preset white balance with a choice of 3200K, 4600K and 5600K.

Note: Bayer white balance must be set in Normal mode.

### 8.4.2 Automatic Gain Control

This function uses gain to maintain a constant output level in accordance with ambient brightness changes. It is also part of the integrated ALC+ capability described in section 8.3.7.

The range of AGC, as well as manual gain adjustment, is -6dB to +24 dB.

The AGC function can be set to ON or OFF.

Note: This is available only in Normal mode.

### 8.4.3 Programmable Look UP table (LUT)

The BM-141GE and BB-141GE have a programmable look-up table (LUT) that lets the user adjust the transfer function of the video output. The look up table has a 256 setting points (for knee and gamma) which can be applied across the full range of input signal. At each point, the gain can be set to produce the required output characteristics. In the case of the BB-141GE, Gr, R, Gb and B signals all have the same characteristics.

If set by the JAI SDK Camera Control Tool, the Gamma setting and LUT cannot be used at the same time. This is because the Gamma setting and LUT use the same data table (see the following diagram for an example).

#### Gamma setting


<b>Analog Control</b>	
Gain Selector	Analog All
Gain Raw	0
Gain Auto	Off
Gain Auto Balance Once	Push to Execute Command ---->
AGC Reference	2816
Black Level Selector	All
Black Level Raw	0
Black Level Auto Balance Once	Push to Execute Command ---->
Balance White Auto	Manual or One Push
Balance White Auto Once	Push to Execute Command ---->
AWB Area	Middle
Inquire Status	0
Gamma Correction	0.45
<b>Device Information</b>	
Device Vendor Name	0.45
Device Model Name	0.6

<b>LUT Controls</b>	
LUT Enable	False
LUT Index	0
LUT Value	4096

Note: LUT Enable is False.


## BM-141GE, OP22-5-1 / BB-141GE, OP22-5-1

When LUT is used, the Gamma setting should be 1.0 (OFF). Then “LUT Enable” is set at “True” (see below).



### 8.4.4 Blemish Compensation circuit

BM-141GE/BB-141GE has a blemish compensation circuit. This function compensates for blemishes on the CCD sensor (typically pixels with extremely high response or extremely low response). This applies to both monochrome and color versions. Pixels that fulfill the blemish criteria can be compensated by adjacent pixels on both columns and, in the case of the BB-141GE, the defective pixels can be compensated by adjacent same Bayer color pixels on both columns. The number of compensations is up to 8 pixels on both L and R channels. The circuit built into the BM-141GE/BB-141GE has an ON/OFF function for the compensation data derived in the factory. The default setting is OFF.



### 8.4.5 Extended temperature operation (-45 °C to +65 °C)

The OP22-5-1 model suffix indicates that the BM-141GE/BB-141GE cameras are individually tested, validated and temperature cycled to certify their operating ability throughout an extended temperature range which is greater than the operating range of typical COTS (commercial off-the-shelf) cameras. Although units are guaranteed to operate throughout the temperature range, operating the camera beyond the standard range of -5 °C to +45 °C may result in some reduced performance characteristics, such as higher noise, reduced SNR, etc. Specifications shown in the camera data sheet and in the table at the back of this document are for when the camera is operating within normal temperature conditions and may be subject to variations when operating in extreme temperatures.



## 8.5. Sensor Layout and timing

### 8.5.1 CCD Sensor Layout

The CCD sensor layout with respect to pixels and lines used in the timing and video full frame read out is shown below.




Fig.19 CCD sensor layout

**Important Note:** By setting the Optical Black (OB) transfer mode, the user can select whether to include optical black pixels in the image stream. This is for horizontal OB only.

**8.5.2 Horizontal timing**

The LVAL period is shown for normal continuous mode.

1 LVAL 1830 clk=31.551 us 1clk=17.241 ns




Fig.20 Horizontal timing

**8.5.3 Vertical timing**

The FVAL period for normal continuous mode full scan is shown.

FULL FRAME READ OUT FRAME RATE 1052L 30.12 fps





Fig.21 Vertical timing for full scan

### 8.5.4 Partial Scanning

The FVAL period is shown for 1/2 partial scan in normal continuous mode.

#### Vertical Timing

The diagram and table below provide vertical timing information for the fixed partial scan settings 2/3, 1/2, 1/4, and 1/8.



Values for vertical timing in partial scan continuous mode.

AREA	FVAL Low (L)	A (L)	B (L)		C (L)	Total line	frame rate
			Start line	End line			
2/3	3	38	694		37 L	772 L	41.05
			173	866			
1/2	3	56	520		54 L	633 L	50.06
			261	780			
1/4	3	82	260		80 L	425 L	74.57
			391	650			
1/8	3	95	130		93 L	321 L	98.73
			455	584			

Fig.22 Vertical timing for partial scanning

**Horizontal Timing**

The horizontal timing is the same for partial scan as for full scanning.

1 LVAL 1830 clk=31.551 us 1clk=17.241 ns




Fig.23 Horizontal Timing for Partial Scanning

**8.5.5 Vertical binning**

Vertical binning combines charge from two adjacent lines, reducing the vertical resolution to half and at the same time increasing frame rate and sensitivity. By activating this function, the frame rate is increased to 50.18 fps.

This function is available only for the BM-141GE.

**Important Note**

Vertical Binning cannot be used together with Partial Scanning.

**Horizontal Timing**

Vertical Binning

1LVAL 2193 ck=37.810 us

1clk=17.241 us




Fig.24 Horizontal Timing for Vertical Binning

**Vertical timing**

Vertical Binning FRAME RATE 527L 50.18 fps




Fig.25 Vertical Timing for Vertical Binning

**8.5.6 Draft mode**

The draft mode function is only available on the BB-141GE. One RG line and one GB line out of each 8 lines are accumulated and read out as one line. Since only two lines are read out from 8 lines, the frame rate is increased to 101.17 frames per second.

**Horizontal timing**

DRAFT 1LVAL 2139 clk 36.879 us




Fig.26 Horizontal timing for Draft mode

**Vertical timing**

Draft Frame rate 268L 101.17 fps




Fig.27 Vertical timing for Draft mode

**8.6. Operation Modes**

This camera can operate in 8 primary modes.

- |   |                                 |
|---|---------------------------------|
| 1. <b>Continuous Mode</b>                     | Pre-selected exposure           |
| 2. <b>Edge Pre-Select Mode (EPS)</b>          | Pre-selected exposure           |
| 3. <b>Pulse Width Control Mode (PWC)</b>      | Pulse width controlled exposure |
| 4. <b>Reset Continuous Trigger Mode (RCT)</b> | Pre-selected exposure           |
| 5. <b>Smearless EPS Mode</b>                  | Pre-selected exposure           |
| 6. <b>Sequential EPS Trigger</b>              | Pre-selected exposure (EPS)     |
| 7. <b>Delayed Readout EPS Trigger</b>         | Pre-selected exposure (EPS)     |
| 8. <b>Delayed Readout PWC Trigger</b>         | Pulse width controlled exposure |

**8.6.1 Continuous Mode**

For applications not requiring asynchronous external triggering, this mode should be used.

In continuous mode it is possible to use a lens with video controlled iris.

For timing details, refer to fig. 20. through fig. 27.

To use this mode:

Set function:	Trigger mode	Continuous
	Scanning	Full, Partial scanning
	Draft mode	ON/OFF (BB-141GE only)
	Vertical binning	ON/OFF (BM-141GE only)
	Shutter mode	Preset, Programmable, Exposure Time Abs, Auto
	Shutter speed	1/30 to 1/10,000
	Programmable exposure	2L to 1052L

### 8.6.2 Edge Pre-Select (EPS) Trigger Mode

An external trigger pulse initiates the capture, and the exposure time (accumulation time) is the fixed shutter speed set by registers. The accumulation can be LVAL synchronous or LVAL asynchronous. The resulting video signal will start to be read out after the selected shutter time.

For timing details, refer to fig. 20. through fig. 29.

To use this mode:

Set function:	Trigger mode	EPS
	Scanning	Full, Partial
	Vertical binning	ON / OFF (BM-141GE only)
	Draft Mode	ON / OFF (BB-141GE only)
	Shutter mode	Preset, Programmable, Exposure Time Abs
	Shutter speed	1/60 to 1/10,000
	Programmable exposure	2L to 1052L
	Accumulation (Auto)	LVAL sync / LVAL async
	Other functions and settings	
Input:	External trigger	GigE interface or 12-pin Hirose

#### Important notes on using this mode

- Trigger pulse >2 LVAL to <1 FVAL
- The following table shows minimum trigger interval in synchronous accumulation mode

Full scan	1054 L
2/3 Partial	774 L
1/2 Partial	635 L
1/4 Partial	427 L
1/8 Partial	323 L
1/2 V Binning	529 L

In the case of asynchronous mode, the exposure time should be added to the above table.

#### LVAL\_sync timing





Fig. 28 Edge Pre-Select LVAL sync timing

LVAL\_async timing



8.6.3 Pulse Width Control (PWC) Trigger Mode

In this mode the accumulation time is equal to the trigger pulse width. Here it is possible to have long exposure times. For best image quality, the maximum recommended time is <2 seconds. Longer exposures may show signs of CCD noise. The accumulation can be LVAL synchronous or LVAL asynchronous. The resulting video signal will start to be read out after the trigger rising edge. For timing details, refer to fig. 20. through fig. 27 and fig.30 and 31.

To use this mode:

Set function:	Trigger mode	PWC
	Scanning	Full, Partial
	Vertical binning	ON / OFF (BM-141GE only)
	Draft Mode	ON / OFF (BB-141GE only)
	Accumulation (Auto)	LVAL sync / LVAL async
	Other functions and settings	
Input:	External trigger	GigE interface or 12-pin Hirose

**Important notes on using this mode**

- Trigger pulse width  $>2LVAL$  to <2 seconds
- The following table shows minimum trigger interval in synchronous accumulation mode

Full scan	1054 L
2/3 Partial	774 L
1/2 Partial	635 L
1/4 Partial	427 L
1/8 Partial	323 L
V Binning	529 L

In the case of asynchronous mode, the exposure time should be added to the above table.



LVAL\_sync timing




Fig. 30 Pulse Width Control LVAL sync.

LVAL\_async timing




Fig.31 Pulse Width Control LVAL async

**8.6.4 Reset Continuous Trigger (RCT) Mode**

The RCT mode operates like EPS (Edge Pre-Select) mode with a smearless function. An external trigger pulse will immediately stop the video read out, reset and restart the exposure, then operate in normal mode until the next trigger. After the trigger pulse is input, a fast-dump readout is performed. In the BM-141GE and BB-141GE, this period is 6.77ms which is 215L. The exposure time is determined by the pre-set shutter speed. If no further trigger pulses are applied, the camera will continue in normal mode and the video signal is not output. The fast dump readout has the same effect as “smearless read out”. Smear associated with bright spots in the image is reduced for the triggered frame. The Reset Continuous Trigger mode enables triggering to be used in conjunction with a lens with video controlled iris without losing proper exposure between triggers.


To use this mode:

Set function:	Trigger mode	RCT
	Scanning	Full, Partial
	Vertical binning	ON / OFF (BM-141GE only)
	Draft Mode	ON / OFF (BB-141GE only)
	Shutter mode	Preset, Programmable, Exposure Time Abs
	Shutter speed	1/60 to 1/10000
	Programmable exposure	2L to 1052 L
	Accumulation	LVAL async
	Other functions and settings	
Input:	External trigger	GigE interface or 12-pin Hirose

**Important notes on using this mode**

- Trigger pulse >2 LVAL to <1 FVAL
- The following table shows minimum trigger interval in synchronous accumulation mode

Full scan	1268 L
2/3 Partial	989 L
1/2 Partial	850 L
1/4 Partial	642 L
1/8 Partial	438 L
1/2 V Binning	744 L



**Fig.32 RCT mode timing**

### 8.6.5 Smearless EPS Trigger Mode

This mode is EPS trigger mode with a smearless function. Once the external trigger is input, a fast dump is activated. Then exposure starts with the preset shutter speed. This mode can eliminate the upper half of the smear associated with bright highlights in the image.

This mode functions only in LVAL asynchronous mode.

To use this mode:

Set function:	Trigger mode	Smearless Edge PreSelect
	Scanning	Full, Partial
	Vertical binning	ON / OFF (BM-141GE only)
	Draft Mode	ON / OFF (BB-141GE only)
	Shutter mode	Preset, Programmable, Exposure Time Abs
	Shutter speed	1/60 to 1/10,000
	Programmable exposure	2L to 1052 L
	Accumulation	LVAL a-sync
	Other functions and settings	
Input:	Ext. trigger.	GigE interface or 12-pin Hirose

#### Important notes on using this mode

- Trigger pulse >2 LVAL to <1 FVAL
- The following table shows minimum trigger interval in synchronous accumulation mode

Full scan	1268 L
2/3 Partial	989 L
1/2 Partial	850 L
1/4 Partial	642 L
1/8 Partial	438 L
1/2 V Binning	744 L




Fig.33 Smearless EPS mode timing

**8.6.6 Sequential Trigger Mode (EPS)**

This mode allows the user to define a preset sequence of up to 10 images, each with its own ROI, Shutter and Gain values. As each trigger input is received, the image data within the preset sequence is output as described below.



Fig. 34 Sequential Trigger Mode

Signals added to a trigger can be selected by 0xB060 Camera Trigger Selector in the register map via GPIO. The camera will function on the rising edge of the trigger and Negative or Positive should be determined accordingly.

The following default settings can be modified by the user to define a sequence.

ID	ROI				Shutter	Gain
	Width	Height	Offset X	Offset Y		
1	1392	1040	0	0	1052	0
2	1392	1040	0	0	1052	0
3	1392	1040	0	0	1052	0
4	1392	1040	0	0	1052	0
5	1392	1040	0	0	1052	0
6	1392	1040	0	0	1052	0
7	1392	1040	0	0	1052	0
8	1392	1040	0	0	1052	0
9	1392	1040	0	0	1052	0
10	1392	1040	0	0	1052	0

The following registers are used to configure the sequence.

- 0xC0F4      Sequence Repetitions (Number of Repetitions)
- 0xC0F8      Sequence Ending Position (Ending Position)
- 0xA30C      Sequence Reset Command (1 only)
- 0xB060      Selection for camera trigger 0
- 0xA040      Trigger mode selection and 0x09 for Sequential PS mode

**Example of settings**

Setting: Repeat 5 times from ID 1 through ID 8

- 0xC0F4      Set to 0x05
- 0xC0F8      Set to 0x08
- 0xB060      For instance, 12p #6 for Optical IN 1
- 0xA040      Sequential PS (9)
- 0xA3F0      Set this for start
- 0xA040      Set Normal Mode (0) for stop

Please refer to the detailed register description on Camera Register Map which is included in the SDK. The following table shows the minimum trigger interval in synchronous accumulation mode. In the case of asynchronous accumulation mode, the exposure time should be added to figures in this table.

Full Scan	2/3 Partial	1/2 Partial	1/4 Partial	1/8 Partial	1/2 V Binning
1054 L	774 L	635 L	427 L	323 L	529 L

- ◆ This table assumes that shutter speed is set the same for all sequences. If the shutter speed is different, the difference of exposure time should be added.
- ◆ It is recommended to set the exposure time in order from the shortest to the longest one.
- ◆ The above table shows the interval at PE=2 (minimum). In case of longer exposures, the interval is (Value on the table - 2) + Exposure lines.
- ◆ Do not input the trigger just after the sequence is reset. It requires at least 500ms delay.
- ◆ ROI can be set by 8-pixel increments in horizontal direction. In vertical direction, ROI minimum increment is 1 line for BM-141GE and 2 lines for BB-141GE.

### 8.6.7 Delayed Readout EPS and PWC Modes (EPS and PWC)

This mode can be used to delay the transmission of a captured image. When several cameras are triggered simultaneously and connected to the same GigE interface, it allows the cameras to be read out in sequence, preventing congestion.

The image data is not transmitted directly by the trigger 0 and is stored in the memory located at Ethernet Interface. By the falling edge of the soft trigger 1, the image data is output.

This mode can work in EPS mode and PWC mode.




Fig.35 Delayed Readout Mode

Example of setting

- 0xA040 PS Delayed Readout (0x17)
- 0xB060 Trigger 0 select, e.g. 0x04 OPT IN 1
- 0xB-064 Trigger 1 select, e.g. 0x05 OPT IN 2


For the details of Registers, please refer to Camera Register Map which is included in the SDK.

**8.6.8 Optical Black Transfer Mode**

It is possible for the user to decide whether the optical black (OB) portion of the image will be transferred or not. The optical black part can be used for black reference in the application software. Setting register 0xA41C turns the optical black transfer ON or OFF. The default condition is OFF.


	OB Transfer Mode OFF	OB Transfer Mode ON
Normal Scan		
2/3 Partial Scan		
1/2 Partial Scan		
1/4 Partial Scan		
1/8 Partial Scan		
V Binning Scan		

Note: The menu for ON or OFF of OB transfer mode is found on the Image Format Control section of the JAI SDK Camera Control Tool.



### 8.6.9 Multi ROI Mode (Multi Region of Interest)

In the trigger mode, a maximum of 5 ROIs located on one image can be output by one trigger input. By using this mode, the data stream can be made smaller. Each ROI can be overlapped.



## 8.7. Operation Mode and Functions matrix

ID Value (Note 1)	Mode	Shutter Preset / Program.	Vertical Binning (Note 2)	Partial Scanning	DRAFT	Multi ROI	LVAL Sync/ Async	Auto Iris output (Note 4)
0x00	Continuous	Yes	Yes	Yes	Yes	No	---	Yes
0x01	Edge Pre-Select (EPS)	Yes	Yes	Yes	No	Yes	Auto	No
0x02	Pulse Width Control (PWC)	Not applicable	Yes	Yes	No	Yes	Auto	No
0x04	RCT	Yes	Yes	Yes	No	Yes	Async	Yes
0x05	Smearless EPS (Note 3)	Yes	Yes	Yes	No	Yes	Async	No
0x09	Sequential EPS	Yes	Yes	Yes	No	No	Async	No
0x17	Delayed Readout EPS	Yes	Yes	Yes	No	Yes	Auto	No
0x18	Delayed Readout PWC	Yes	Yes	Yes	No	Yes	Auto	No

Note 1: Write ID in register address 0xA040 in order to set trigger mode.

Note 2: Vertical Binning is available only for BM-141GE.

Note 3: Smearless EPS modes suppress the upper half of the smear

Note 4: The auto iris output is only effective in normal scan and vertical binning modes. It is not available in partial scan mode and draft mode.


## 8.8. Special notes for settings

### 8.8.1 When the image size is changed

If the image size needs to be changed while the image is being captured, stop the image capturing by pressing “Stop Acquisition”. Then change the value. It is possible to set shutter values and gain settings while watching the picture on the screen.


### 8.8.2 When the image is captured

While capturing image, if the frame rate is decreased, please check the packet size. Each packet includes header information. If the packet size is small, the percentage of header data vs. image data can become significant in the output rate. Accordingly, the frame rate may be slower than expected. In this case, it is recommended to set the packet size at a higher value. Please note that the packet size is not stored, and it is necessary to set it on every start up. The current frame rate is shown on the bottom of the camera control tool.



### 8.8.3 Acquisition frame rate

Acquisition frame rate is a function for controlling the rate of image capture in Continuous mode. The frame rate can be set at full speed, 1/2, 1/4 and 1/8. If a trigger mode is used, it is strongly recommended to use the full frame rate. Otherwise, the trigger frequency will also be divided according to the frame rate setting.



Note: The above figure shows an example from a 15.05 fps camera.



## 9. Register Map

The table below provides detailed information for the hardware registers used for controlling the camera and obtaining information on the status of the camera. The content of this register map is also found in the XML file, as stipulated by the GenICam standard.

### Device Information

Address	Display Name (JAI Control Tool)	GenICam name	Read / Write	Size	Value / Range of value	Description	Default value
0x0048	Device Vendor Name	DeviceVendorName	R	32		Manufacture of this device	
0x0068	Device Model Name	DeviceModelName	R	32		Model Name of this device	
0x0088	Device Version	DeviceVersion	R	32		Version of this device	
0x00A8	Device Manufacturer Info	DeviceManufacturerInfo	R	48		Provides extended manufacturer information about the device.	
0x00D8	Device ID	DeviceID	R	16		Camera serial number	
0x00E8	Device User ID	DeviceUserID	RW	16		User assignable string (16 Byte)	
0xA714	FPGA version	DeviceFPGAVersion	R	4			
0xA640	Device Reset	DeviceReset	W	4	Command=1		
0xA1FC	Temperature	Temperature	R	4	0.0625° step	-55 °C ~ 150 °C	

### Image Format Control

Address	Display Name (JAI Control Tool)	GenICam name	Read / Write	Size	Value / Range of value	Description	Default value
0xA400	Width Max	WidthMax	R	4	1392	Width max	1392
0xA404	Height Max	HeightMax	R	4	1040	Height max	1040
0xA410	Pixel Format	PixelFormat	RW	4	<u>Mono CCD(BM-500GE)</u> 0x01080001 0x010C0004 0x01100003 0x01100005 0x010C0006 <u>Bayer CCR(BB=500GE)</u> 0x01080009 0x0108000A 0x0110000D 0x0110000E 0x01100011 0x011000112	Mono8 Mono10Packed Mono0 Mono12 Mono12Packed BayerRG8 BayerGB8 BayerRG10 BayerGB10 BayerRG12 BayerGB12	Mono8 BayerRG8
0xA500	ROI Mode	ROIMode	RW	4	1 to 5	1:ROI disable 2 to 5: Enable	1
0xA504	ROI 1 Width	Width	RW	4	8 - 1392	Width	W.Max
0xA508	ROI 1 Height	Height	RW	4	8 - 1040	Height	H.Max
0xA50C	ROI 1 Offset X	OffsetX	RW	4	0 - 1384	Horizontal offset	0
0xA510	ROI 1 Offset Y	OffsetY	RW	4	0 - 1032	Vertical offset	0
0xA514	ROI 2 Width	Width2	RW	4	8 - 1392	Width 2	W.Max
0xA518	ROI 2 Height	Height2	RW	4	8 - 1040	Height 2	H.Max

## BM-141GE, OP22-5-1 / BB-141GE, OP22-5-1

0xA51C	ROI 2 Offset X	OffsetX2	RW	4	0 - 1384	Offset X2	0
0xA520	ROI 2 Offset Y	OffsetY2	RW	4	0 - 1032	Offset Y2	0
0xA524	ROI 3 Width	Width3	RW	4	8 - 1392	Width 3	W.Max
0xA528	ROI 3 Height	Height3	RW	4	8 - 1040	Height 3	H.Max
0xA52C	ROI 3 Offset X	OffsetX3	RW	4	0 - 1384	Offset X3	0
0xA530	ROI 3 Offset Y	OffsetY3	RW	4	0 - 1032	Offset Y3	0
0xA534	ROI 4 Width	Width4	RW	4	8 - 1392	Width 4	W.Max
0xA538	ROI 4 Height	Height4	RW	4	8 - 1040	Height 4	H.Max
0xA53C	ROI 4 Offset X	OffsetX4	RW	4	0 - 1384	Offset X4	0
0xA540	ROI 4 Offset Y	OffsetY4	RW	4	0 - 1032	Offset Y4	0
0xA544	ROI 5 Width	Width5	RW	4	8 - 1392	Width 5	W.Max
0xA548	ROI 5 Height	Height5	RW	4	8 - 1040	Height 2	H.Max
0xA54C	ROI 5 Offset X	OffsetX5	RW	4	0 - 1384	Offset X 5	0
0xA550	ROI 5 Offset Y	OffsetY5	RW	4	0 - 1032	Offset Y 5	0
0xA080	Partial scan	PartialScan	RW	4	0=Full frame 1=2/3 2=1/2 3=1/4 4=1/8 15=Variable		
0xA088	Variable Partial Scan Start Line	VariablePartialScanStartLine	RW	4	1 - 1025		
0xA08C	Variable Partial Scan Num. of Lines	VariablePartialScanNumOfLines	RW	4	2 - 1032		
0xA084	Binning Vertical	BinningVertical	RW	4	1=Binning OFF 2=1/2 V Binning	Only BM-141GE	1
0xA094	Draft Mode	DraftMode	RW	4	0= OFF 1= ON	Only BB-141GE	0
0xA13C	Test Image Selector	TestImageSelector	RW	4	0=OFF 4=H Ramp Scale 5=V Ramp Scale 6= Moving Ramp Scale 8=Normal Color bar 9=Vertical Color Bar 10=Moving Color Bar	8,9,10 only for BB-141GE	0
0xA41C	OB Transfer Enable	OBTransferEnable	RW	4	0=OFF 1=ON		0

### Acquisition and Trigger Control

Address	Display Name (JAI Control Tool)	GenICam name	Read / Write	Size	Value / Range of value	Description	Default value
0xA604	Acquisition Mode	AcquisitionMode	RW	4	0=Stop 1=Start	Acquisition start and stop	0
0xA414	Acquisition frame rate	AcquisitionFrameRate	RW	4	0=Full speed 1=1/2 speed 2=1/4 speed 3=1/8 speed		0
0xA000	Shutter mode	ShutterMode	RW	4	0 = Preset shutter 1= Programmable exposure in line 2=Programmable exposure(us) 3=Auto Exposure Constantly	Sets exposure time for image capture.	1
0xA004	Preset shutter	PresetShutter	RW	4	0=Off; 1=1/60 2=1/100 3=1/250; 4=1/500; 5=1/1000; 6=1/2000; 7=1/4000; 8=1/8000; 9=1/10000;	Fixed values for setting exposure	0
0xA008	Exposure Time Raw	ExposureTimeRaw	RW	4	2 to 1052 (OFF)	Flexible setting of exposure time ranging from 64 $\mu$ s to 66.44 ms using the LVAL period (L) as increment. 1L is 32.07 $\mu$ s.	1052
0xA018	Exposure Time (us)	ExposureTimeAbs	RW	4	63 to 33192 ( OFF)	Actual exposure time in microseconds, $\mu$ s. The camera will round value off to match LVAL increments.	33192
0xA030	Auto exposure value	AutoExposureValue	R	4		Exposure time on Auto exposure mode	
0xA040	Exposure Mode	ExposureMode	RW	4	00=Continuous trigger 01=Edge pre-select 02=Pulse-width control 04=RCT mode 05=Smearless EPS 09=Sequential EPS 17=Delayed EPS 18=Delayed PWC		0

### Analog Control

Address	Display Name (JAI Control Tool)	GenICam name	Read / Write	Size	Value / Range of value	Description	Default value
0xA0A0	Digital Gr	DigitalGr	RW	4	0 ~ 16384		
0xA0A4	Digital Gb	DigitalGb	RW	4	0 ~ 16384		
0xA0A8	Digital Red	DigitalRed	RW	4	0 ~ 16384		
0xA0AC	Digital Blue	DigitalBlue	RW	4	0 ~ 16384		
0xA0B0	Gain Auto	GainAuto	RW	4	0=OFF 1=continuous		0

## BM-141GE, OP22-5-1 / BB-141GE, OP22-5-1

0xA0B4	AGC Reference	AGCReference	RW	4	0 to 8192	Reference value for AGC as well as Auto shutter	0
0xA0B8	Gain Auto Balance Once	GainAuotBalanceOnce	RW	4	Command=0		0
0xA0BC	Black Level Auto Balance Once	BlackLevelAuotBalanceOnce	RW	4	Command=0		0
0xA09C	Analog Fine Tap 2	AnalogFineTap2	RW	4	-64 to 63		0
0xA0C4	Analog All	AnalogAll	RW	4	-84 to 341	Master gain level	0
0xA0C0	Balance White Auto	BalanceWhiteAuto	RW	4	0=Manual or one push 1=Continuous 2=3200K 3=4600K 4=5600K	BB-141GE only	
0xA0D0	Balance White Auto Once	BalanceWhiteAutoOnce	W	4	Command=0		0 only
0xA0D8	Status of video processing	StatusOfProcessing	R	4	0=Complete 1=Too bright 2=Too dark 3=Timeout error 4=Busy 5=Reaching a limit of Feature's value 6=Inappropriate trigger mode	For auto white balance, Exposure Mode should be 0=Continuous.	
0xA0D4	AWB Area Enable	AWBAreaEnable	RW	4	0=Full area 1=Upper left 2=Upper middle 3=Upper right 4=Middle left 5=Middle middle 6=Middle right 7=Lower left 8=Lower middle 9=Lower right	Block 1~ Block 9 Image is divided in 9	5
0xA0EC	Gamma Correction	GammaCorrection	RW	4	0=OFF (Gamma 1.0) 1=Gamma 0.45 2=Gamma 0.6		

### Image Processing

Address	Display Name (JAI Control Tool)	GenICam name	Read / Write	Size	Value / Range of value	Description	Default value
0xA128	Blemish Reduction Enable	BlemishReductionEnable	RW	4	0=OFF 1=ON		0

### Digital IO

Address	Display Name (JAI Control Tool)	GenICam name	Read / Write	Size	Value / Range of value	Description	Default value
0xA600	Software Trigger 0	SoftwareTrigger0	RW	4	0 to 1		
0xA644	Software Trigger 1	SoftwareTrigger1	RW	4	0 to 1		
0xA648	Software Trigger 2	SoftwareTrigger2	RW	4	0 to 1		
0xA64C	Software Trigger 3	SoftwareTrigger3	RW	4	0 to 1		
0xB060	Line Selector Camera trigger 0	LineSelectorCameraTrigger0	RW	4	Line Source 127:OFF 0:LVAL 1:DVAL 2:FVAL 3:EEN 4:GPIO_PortIn1(Opt In1) 5:GPIO_PortIn2(Opt In2) 6: GPIO_PortIn3(TTL In) 7: GPIO_PortIn4(LVDS In) 12:Software Trigger 0 13: Software Trigger 1 14: Software Trigger 2 15: Software Trigger 3 16:Pulse Generator 0 17:Pulse Generator 1		
0xB064	Line Selector Camera Trigger 1	LineSelectorCameraTrigger1	RW	4			
0xB070	Line Selector GPIO Port 1(TTL Out 1)	GPIO_Port1	RW	4			
0xB074	Line Selector GPIO Port 2(TTL Out 2)	GPIO_Port2	RW	4			
0xB078	Line Selector GPIO Port 3(Optical Out 1)	GPIO_Port3	RW	4		Line Source Bit31 - Bit25	
0xB07C	Line Selector GPIO Port 4(Optical Out 2)	GPIO Port 4	RW	4		Bit24:Line Inverter 0=False (Active High) 1=True(Active Low)	
0xB090	Line Selector Pulse Generator 0	PulseGenerator0	RW	4			
0xB094	Line Selector Pulse Generator 1	PulseGenerator1	RW	4			
0xB0A0	Line Selector TimeStamp Reset	TimeStampReset	RW	4			
0xB0A4	Line Selector Sequence Table Reset	SequenceTableReset	RW	4			

### Pulse Generator

Address	Display Name (JAI Control Tool)	GenICam name	Read / Write	Size	Value / Range of value	Description	Default value
0xB004	Clock Pre-scaler	ClockPreScaler	RW	4	0x000 0x001 0x002   0xFFF	Bypass Divide by 2 Divide by 3   Divide by 4096	0
0xB008	Pulse Generator Length 0	PulseGeneratorLength0	RW	4	1~1048575	Defines the length of the counter 0	1
0xB00C	Pulse Generator Start Point 0	PulseGeneratorStartPoint0	RW	4	0~1048574	Defines the starting point of the counter 0	0
0xB010	Pulse Generator Repeat Count 0	PulseGeneratorRepeatCount0	RW	4	0 - 255	Defines the repeat count of the counter 0	0
0xB014	Pulse Generator End Point 0	PulseGeneratorEndPoint0	RW	4	1~1048575	Defines the end point of the counter 0	1
0xB018	Clear Mode for the Pulse Generator 0	PulseGeneratorClear0	RW	4	0 :Free Run 1:High Level 2: Low Level 4: Rising Edge 8: Falling Edge		0

## BM-141GE, OP22-5-1 / BB-141GE, OP22-5-1

0xB01C	Pulse Generator Length 1	PulseGeneratorLength1	RW	4	1~1048575	Defines the length of the counter 1	1
0xB020	Pulse Generator Start Point 1	PulseGeneratorStartPoint1	RW	4	0~1048574	Defines the starting point of the counter 1	0
0xB024	Pulse Generator Repeat Count 1	PulseGeneratorRepeatCount1	RW	4	0 - 255	Defines the repeat count of the counter 1	0
0xB028	Pulse Generator End Point 1	PulseGeneratorEndPoint1	RW	4	1~1048575	Defines the end point of the counter 1	1
0xB02C	Clear Mode for the Pulse Generator 1	PulseGeneratorClear1	RW	4	0 :Free Run 1:High Level 2: Low Level 4: Rising Edge 8: Falling Edge		0

### Sequence Acquisition Mode

Address	Display Name (JAI Control Tool)	GenICam name	Read / Write	Size	Value / Range of value	Description	Default value
	Sequence Selector	SequenceSelector			Sequence Selector Val 0=Sequence 1 1=Sequence 2 2=Sequence 3 3=Sequence 4 4=Sequence 5 5=Sequence 6 7=Sequence 8 8=Sequence 9 9=Sequence 10	Sequence Selector value is the INDEX for each sequence.	
0xC000	Sequence Exposure Time Raw	SequenceExposureTimeRaw	RW	4	2 to 1052	Shutter value Base Address INDEX=0 to 9 (Base Address + Index *4)	1052
0xC078	Sequence Master Gain Raw	SequenceMasterGain	RW	4	-170 to 700	Gain value Base Address INDEX=0 to 9 (Base Address + Index *4)	0
0xC0FC	Sequence ROI Size X	SequenceROISizeX	RW	4	8 - 1392	ROI width value Base Address INDEX=0 to 9 (Base Address + Index *4)	Width max
0xC124	Sequence ROI Size Y	SequenceROISizeY	RW	4	8 - 1040	ROI Height value Base Address INDEX=0 to 9 (Base Address + Index *4)	Height Max
0xC14C	Sequence ROI Offset X	SequenceROIOffsetX	RW	4	0 - 1384	ROI H Offset value Base Address INDEX=0 to 9 (Base Address + Index *4)	0
0xC174	Sequence ROI Offset Y	SequenceROIOffsetY	RW	4	0 - 1032	ROI V Offset value Base Address INDEX=0 to 9 (Base Address + Index *4)	0
0xC19C	Repeat Count in Each Step	SequenceRepeatCountInEachStep	RW	4	0 to 255	Sequence repeat count value Base Address INDEX=0 to 9 (Base Address + Index *4)	0
0xA30C	Save Sequence Settings	SequenceSaveCommand	RW	4	1 only	Save sequence	1
0xC0F0	Reset Sequence Settings	SequenceResetCommand	RW	4	1 only	Sequence reset	1
0xC0F4	Sequence Repetition Count	SequenceRepetitions	RW	4	0 to 255	Sequence repeat count	0
0xC0F8	Last Sequence	SequenceEndingPosition	RW	4	1 to 10	Last sequence number setting	1



GigE Transport Layer

Address	Display Name (JAI Control Tool)	GenICam name	Read / Write	Size	Value / Range of value	Description	Default value
0xA418	Payload size	PayloadSize	R	4		Return image size of 1 frame	
0x0000	GigE Major Version	GevVersionMajor	R	4		Version of the GigE Standard to which the device is compliant.	0001
	GigE Minor Version	GevVersionMinor					0000
0x0004	Is Big Endian	GevDeviceModelsBigEndian	R	4	0:Little-endian 1:Big-endian	0:Little endian 1:Big endian	1
	Character set	GevDeviceModeCharacterSet			0:Unknown ,1:UTF-8		1
0x0008	MAC address	GevMacAddress	R	4		Upper 4 bytes of the MAC address	
0x000c	MAC address	GevMacAddress	R	4		Lower 4 bytes of the MAC address	
0x0010	Support LLA	GevSupportedIPConfigurationLLA	R	4	Bit 31: persistent Bit 30: DHCP Bit 29: LLA	Bits can be OR-ed. All other bits are reserved and set to 0. DHCP and LLA bits must be on.	All True
	Support DHCP	GevSupportedConfigurationDHCP					
	Support Persistent IP	GevSupportedConfigurationPersistentIP					
0x0014	Current IP configuration LLA	GevCurrentIPConfigurationLLA	RW	4	Bit 31: persistent Bit 30: DHCP Bit 29: LLA	Bits can be OR-ed. LLA is always activated and is read only.	LLA is always true
	Current IP configuration DHCP	GevCurrentIPConfigurationDHCP					
	Current IP configuration Persistent IP	GevCurrentIPConfigurationPersistentIP					
0x0024	Current IP address	GevCurrentIPAddress	R	4			
0x0034	Current Subnet Mask	GevCurrentSubnetAddress	R	4			
0x0044	Current Default Gteway	GevCurrentDefaultGateway	R	4			
0x0200	First URL	GevFirstURL	R	512		File extension .XML indicates uncompressed text file. File extension .ZIP indicates compressed using ZIP.	
0x0400	Second URL	GevSecondURL	R	512			
0x0600	Number Of Interfaces	GevNumberOfInterfaces	R	4		Indicates the number of physical network interfaces on this device.	
0x064C	Persistent IP Address	GevPersistentIPAddress	RW	4		Valid if Persistent IP is enabled	0xCOA86401
0x065C	Persistent Subnet Mask	GevPersistentSubnetMask	RW	4		Valid if Persistent IP is enabled	0xFFFFFFFF00
0x066C	Persistent Default Gateway	GevPersistentDefaultGateway	RW	4		Valid if Persistent IP is enabled	0x00000000
0x0900	Message Channel Count	GevMessageChannelCount	R	4		number of available message channel	1
0x0904	Stream Channel Count	GevStreamChannelCount	R	4		number of available stream channel	1
0x0934	Supported Optional Commands EVENTDATA	GevSupportedOptionalCommandsEVENTDATA	R	4	Bit 31:multiple read Bit 30:WRITEMEM Bit29:PACKETRESEND Bit 28:EVENT Bit 27:EVENTDATA Bit 1:Serial No. Bit 0:User defined name  0=false 1=True	This is a capability register indicating which one of the non-mandatory GVCP commands are supported by this device.	
	Supported Optional Commands EVENT	GevSupportedOptionalCommandsEVENT					
	Supported Optional Commands PACKET RESEND	GevSupportedOptionalCommandsPACKETRESEND					
	Supported Optional Commands WRITEMEM	GevSupportedOptionalCommandsWRITEMEM					
	Supported Optional Commands Concatenation	GevSupportedOptionalCommandsConcatenation					

## BM-141GE, OP22-5-1 / BB-141GE, OP22-5-1

0x0938	Heartbeat Timeout	GevHeartbeatTimeout	RW	4	0 ~ 4294967295		15000
0x093C	Timestamp Tick Frequency	GevTimestampTickFrequency	R	4	Timestamp tick frequency is 0 if timestamp is not supported.	In milliseconds. Internally, the heartbeat is rounded according to the clock used for heartbeat.	
0x0940		GevTimestampTickFrequency	R	4		64-bit value indicating the number of timestamp clock ticks in 1 second. This register holds the most significant bytes.	0
0x0944	Timestamp control Latch	GevTimestampcontrolLatch	W	4	Command 2	This register holds the least significant bytes. Used to latch the current timestamp value. No need to clear to 0.	62500000
	Timestamp control Reset	GevTimestampcontrolReset			Command 1		
0x0948	Timestamp Tick Value	GevTimeStampValue	R	4	High	Latched value of the timestamp (most significant bytes)	
0x094C		GevTimeStampValue	R	4	Low	Latched value of the timestamp (least significant bytes)	
0x0A00	Control Channel Privilege Feature	GevCCP	R	4	0:Disconnect 1:Exclusive 2:Control 3:Exclusive Control	control channel privilege register	0
0x0B00	Message Channel Port	GevMCPHostPort	R	4		message channel port register	0
0x0B10	Message Channel Destination Address	GevMCDA	R	4		message channel destination address register	
0x0B14	Message Channel Transmission Timeout	GevMCTT	R	4		message channel transfer timeout: ms	300
0x0B18	Message Channel Retry Count	GevMCRC	R	4		message channel retry count	2
0x0D00	Stream Channel Port	GevSCPHostPort	R	4		primary stream port register	
0xD04	Fire Test Packet	GevSCPSFireTestPacket	RW	4	1	The device will fire one test packet of size specified by the packet size. The don't fragment bit of IP header must be set for this test packet.	
0x0D04	Packet Size	GevSCSPacketSize	RW	4	1428 ~ 16384	primary stream channel packet size register / packet size includes IP, UDP&GVSP Header	1428
	Do Not Fragment (cont.)	GevSCPSDoNotFragment			0=False 1=True	This bit is copied into the "don't fragment" Ebit of IP header of each stream packet. It can be used by the application to prevent IP fragmentation of packets on the stream channel.	1
0x0D08	Packet Delay	GevSCPD	RW	4	0 ~ 125000	Set the delay in between packets	0
0x0D18	Stream Channel Destination Address	GevSCDA	R	4		primary stream channel destination address register	
0xA610	Event GEV_EVENT_TRIGGER Enabled	GevEventTrigger	RW	4	Bit31:Gev Event Trigger Bit30:Gev Event Start	Indicate event message on message channel if it is enable	



Event GEV_EVENT_START_OF_EXPOSURE Enabled	GevEventStartOfExposure	RW	4	Of Exposure Bit29:Gev Event End Of Exposure Bit28:Gev Event Start Of Transfer Bit27:Gev Event End Of Transfer Bit26:Gev Event Trigger Error	
Event GEV_EVENT_END_OF_EXPOSURE Enabled	GevEventEndOfExposure	RW	4		
Event GEV_START_OF_TRANSFER Enabled	GevEventStartOfTransfer	RW	4		
Event GEV_END_OF_TRANSFER Enabled	GevEventEndOfTransfer	RW	4		

**LUT Controls**

Address	Display Name (JAI Control Tool)	GenICam name	Read / Write	Size	Value / Range of value	Description	Default value
0xA200	LUT Enable	LUTEnable	R W	4			
0xD000   0xD3FC	LUT Value	LUTValue[Red]	R W	4	1024 ~ 16384	D000 to D3FC is LUT Index(0 to 255)	4096

**User Sets**

Address	Display Name (JAI Control Tool)	GenICam name	Read / Write	Size	Value / Range of value	Description	Default value
0xA300	UserSet Save	UserSetSave	W	4	1=User area1 2=User area2 3=User area3	Allows use to save all camera settings. Last used area number becomes new default.	1
0xA304	UserSet Load	UserSetLoad	W	4	0=Factory area 1=User area1 2=User area2 3=User area3	Allow the user to recall all camera settings.	0
0xA308	UserSet Selector	UserSetSelector	RW	4	When receiving following commands, store the parameters 0xA300 0xA304	Check the used data, 0=Factory or 1=User	0

## 10. External Appearance and Dimensions




Fig. 36 Outline.

## 11. Specifications

### 11.1 Spectral response




Fig.37 Spectral response for BM-141GE




Fig.38 Spectral response for BB-141GE

## BM-141GE, OP22-5-1 / BB-141GE, OP22-5-1

### 11.2 Specification table

Specifications	BM-141GE	BB-141GE
Scanning system	Progressive scan	
Frame rate full frame	30.12 frames/sec. Progressive (1052 lines/frame)	
Pixel clock	58 MHz	
Line frequency	31.693 kHz (1H = 31.551 $\mu$ s) (1830 pixel clock/line)	
CCD sensor	2/3 inch Monochrome ICX285AL	2/3 inch Bayer Color ICX285AQ
Sensing area	8.98 (h) x 6.7 (v) mm 2/3 inch diagonal	
Cell size	6.45 $\mu$ m (h) x 6.45 $\mu$ m (v)	
Active pixels	1392 (h) x 1040 (v)	
Pixels in video output. Full Scan 2/3 partial Scan 1/2 partial Scan 1/4 partial Scan 1/8 partial Scan Variable Partial Scan Vertical Binning Draft Region-of-interest (ROI)	1392 (h) x 1040 (v) 30.12 fps. H = 31.693 kHz 1392(h) x 694 (v) 41.05 fps H= 31.693 kHz 1392 (h) x 520 (v) 50.06 fps. H = 31.693 kHz 1392(h) x 260 (v) 74.57 fps. H = 31.693 kHz 1392 (h) x 130 (v) 98.73 fps. H = 31.693 kHz Start line from 1 to 1025, height(lines) from 8 to 1032 1392 (h) x 520 (v) 50.18 fps. H = 26.447kHz ( BM-141GE only) 1392 (h) x 260 (v) 101.17 fps. H = 27.128 kHz (BB-141GE only) User definable memory read-out Note: Partial scan cannot be used with Vertical Binning or Draft mode	
Sensitivity on sensor (minimum)	0.03 Lux (Max. gain, Shutter OFF, 50% video )	0.2 Lux (Max. gain, Shutter OFF, 50% Green, w/IR cut filter)
S/N ratio	More than 58 dB (0dB gain, standard temp.)	
Digital Video output	GigE Vision Compliant Mono8, Mono10, Mono10_Packed Mono 12, Mono12_Packed	GigE Vision Compliant BAYRG8, BAYGB8, BAYRG10, BAYGB10 BAYRG12, BAYGB12
White Balance	n/a	Manual/One push Continuous Auto (3200K to 9000K) Preset (3200K, 4600K, 5600K)
Iris video output. Analog	0.7 V p-p , enabled by internal switch	
Gain	Manual / AGC : -6 to +24 dB (1 Step 0.0358 dB)	
Blemish Correction	ON / OFF	
LUT (Look Up table)	OFF: $\gamma=1.0$ ON: $\gamma=0.45$ , LUT ( 256 points)	
Synchronization	Internal/external hardware trigger via GPIO. SW trigger via GigE Vision.	
GPIO Module Input/output switch Clock Generator ( One) Pulse Generators ( Two)	Configurable 16-in / 12-out switch 12-bit counter based on Pixel clock 19-bit counter programmable for length, start point, stop point, repeat	
Hardware Trigger modes	Edge Pre-Select , Pulse Width Control, RCT, Frame Delay and Sequence	
Smearless mode	Available for EPS (Async)	
OB area transfer mode	ON / OFF	
Event message	SYNC / ASYNC mode ( Trigger mode status when exposure starts ) Exposure start, Exposure end, Trigger IN, Video start, Video end	
Electronic Shutter Preset Shutter speed Programmable exposure Exposure Time (Abs) Exposure Auto continuous Pulse Width	OFF(1/30) and 1/60 to 1/10,000 in 9 steps 2L(63 $\mu$ s) to 1052 L ( 33.19 ms) in 1L steps $\mu$ sec - user definable. Same range as PE 64L to 1052L (1/500s to 1/30s) 63 $\mu$ s to 2 sec.	



Specifications	BM-141GE	BB-141GE
Control interface	Register based. GigE Vision / Genlcam compliant	
Functions controlled via GigE Vision Interface	Shutter, Gain, Black Level, Trigger mode, Readout mode, GPIO setup ,ROI ( Genlcam mandatory functions )	
GigE Vision Streaming Control	Packet size, Delayed ( Frame ) readout, inter-packet delay Jumbo frame can be set at max. 16K (16384), default packet size is 1428 Byte.	
Indicators on rear panel	Power, Hardware trigger, GigE Link, GigE activity	
Operating temperature	-40°C to +65°C (Some reduced performance may occur when operating outside the standard -5°C to +45°C range)	
Humidity	20 - 90% non-condensing	
Storage temp/humidity	-50°C to +70°C/20% to 90 % non-condensing	
Vibration	10G (20Hz to 200Hz, XYZ)	
Shock	70G	
Regulatory	CE (EN61000-6-2 and EN61000-6-3), FCC part 15 class B, RoHS, WEEE	
Power	12V DC ± 10%. 5.1 w	
Lens mount	C-mount Rear protrusion on C-mount lens must be less than 10.0mm	
Optical Low Pass Filter	Built in (Only for BB-141GE)	
Dimensions	55 x 55 x 55 mm (H x W x D)	
Weight	230 g	230 g

*Note1: When Gain is set at -4.5db to -6dB, the linearity of the video output may be deteriorated around 100% video output level. Please confirm the output level characteristics when -4.5dB to -6dB gain is set.*

*In order to get specified performance, approx. 30 minutes pre-heating is required.*

*Above specifications are subject to change without notice*

## **12. Appendix**

### **12.1. Precautions**

Personnel not trained in dealing with similar electronic devices should not service this camera.

The camera contains components sensitive to electrostatic discharge. The handling of these devices should follow the requirements of electrostatic sensitive components.

Do not attempt to disassemble this camera.

Do not expose this camera to rain or moisture.

Do not face this camera towards the sun, extreme bright light or light reflecting objects, including laser sources.

When this camera is not in use, put the supplied lens cap on the lens mount.

Handle this camera with the maximum care.

Operate this camera only from the type of power source indicated on the camera.

Remove power from the camera during any modification work, such as changes of jumper and switch settings.

### **12.2. Typical Sensor Characteristics**

The following effects may be observed on the video monitor screen. They do not indicate any fault of the camera, but are associated with typical sensor characteristics.

#### **V. Aliasing**

When the camera captures stripes, straight lines or similar sharp patterns, a jagged image on the monitor may appear.

#### **Blemishes**

All cameras are shipped without visible image sensor blemishes.

Over time some pixel defects can occur. This does not have a practical effect on the operation of the camera. These will show up as white spots (blemishes).

Exposure to cosmic rays can cause blemishes to appear on the image sensor. Please take care to avoid exposure to cosmic rays during transportation and storage. It is recommended to use sea shipment instead of air transportation in order to limit the influence of cosmic rays on the camera.

Pixel defects/blemishes may also emerge due to prolonged operation at elevated ambient temperature, due to high gain setting or during long time exposure. It is therefore recommended to operate the camera within its specifications.

#### **Patterned Noise**

When the sensor captures a dark object at high temperature or is used for long time integration, fixed pattern noise may appear in the image.

### **12.3. Caution when mounting a lens on the camera**

When mounting a lens on the camera dust particles in the air may settle on the surface of the lens or the image sensor of the camera. It is therefore important to keep the protective caps on the lens and on the camera until the lens is mounted. Point the lens mount of the camera downward to prevent dust particles from landing on the optical surfaces of the camera. This

---

work should be done in a dust free environment. Do not touch any of the optical surfaces of the camera or the lens.

#### **12.4. Exportation**

When exporting this product, please follow the export regulation of your own country.

#### **12.5. References**

1. This manual for BM-141GE, OP22-5-1 / BB-141GE, OP22-5-1 can be downloaded from [www.jai.com](http://www.jai.com)
2. Datasheet for BM-141GE, OP22-5-1 / BB-141GE, OP22-5-1 can be downloaded from [www.jai.com](http://www.jai.com)
3. Camera control software can be downloaded from [www.jai.com](http://www.jai.com)

Index

<b>A</b>		<b>I</b>	
Auto Iris Lens.....	41	Inter-Packet Delay .....	26
<b>B</b>		<b>L</b>	
Bit Allocation.....	22, 23	Lens mount.....	74
Blemishes .....	75	<b>N</b>	
<b>C</b>		Network Interface Cards .....	26
CAMERA TRIGGER.....	16	<b>P</b>	
Cat6 Ethernet .....	26, 27	partial scan .....	48
CCD sensor.....	73	Partial scanning .....	48
CCD Sensor .....	46	Pixel Type .....	22, 23
continuous.....	26, 36, 47, 48, 51	Pixels in video output .....	73
<b>D</b>		Preset Shutter .....	73
Delayed Readout Mode .....	26, 58	Pulse width control(PWC).....	36
Draft.....	39, 50	<b>R</b>	
<b>E</b>		RCT .....	55
Edge pre-select(EPS).....	36	<b>Register</b> .....	20, 21, 37, 58
Electronic Shutter .....	39	ROI.....	57
EPS.....	20, 21	<b>S</b>	
Exposure Time Abs.....	39, 40	SDK .....	39, 58
external trigger .....	43	Sequential trigger.....	36
<b>G</b>		Smearless.....	56
Gain .....	73, 74	Spectral response .....	72
GenlCam .....	40	Switches/Routers .....	26
Gigabit Ethernet.....	10	Synchronization .....	73
GigE Vision compliant.....	26	<b>T</b>	
GigE Vision Streaming Protocol .....	22, 23	transmission bandwidth.....	26
GPIO .....	16, 41, 57	Trigger input.....	42
GPIO programming examples .....	20	Trigger mode .....	51, 52, 53, 55, 56
<b>H</b>		<b>V</b>	
Hirose .....	26, 53	Vertical Binning .....	36, 37, 49





## User's Record

Camera type: BM-141GE, OP22-5-1 / BB-141GE, OP22-5-1  
Revision: .....  
Serial No. ....  
Firmware version. ....

*For camera revision history, please contact your local JAI distributor.*

---

## User's Mode Settings.

## User's Modifications.

---

Company and product names mentioned in this manual are trademarks or registered trademarks of their respective owners. JAI A-S cannot be held responsible for any technical or typographical errors and reserves the right to make changes to products and documentation without prior notification.

---

### **Europe, Middle East & Africa**

Phone +45 4457 8888  
Fax +45 4491 8880

### **Asia Pacific**

Phone +81 45 440 0154  
Fax +81 45 440 0166

### **Americas**

Phone (toll-free) +1 800 445  
5444  
Phone +1 408 383 0300

**Visit our web site at [www.jai.com](http://www.jai.com)**



**See the possibilities**